

<b>ALFA ROMEO</b>			
<b>ALFA ROMEO 145</b>			
1.3	1994-97	700	ISO 46
1.4	1994-97	700	ISO 46
1.6	1994-97	700	ISO 46
1.7	1994-97	700	ISO 46
JTD	1998-01	800	ISO 100
TD	1994-01	700	ISO 150
TS	1996-01	700	ISO 100
<b>ALFA ROMEO 146</b>			
1.3	1994-97	700	ISO 46
1.4	1994-97	700	ISO 46
1.6	1994-97	700	ISO 46
1.7	1994-97	700	ISO 46
JTD	1998-01	800	ISO 100
TD	1994-01	700	ISO 150
TS	1996-01	700	ISO 100
<b>ALFA ROMEO 147</b>			
1600-16V-TS		550	ISO 46
1900-JTD		500	ISO 46
1900-JTD-16V		500	ISO 46
2000-16V-TS		550	ISO 46
2000-JTS		500	ISO 46
3200-GTA		500	ISO 46
<b>ALFA ROMEO 155</b>			
1,9D	-->1997	700	ISO 150
1.6	1995-97	700	ISO 100
1.7-TS	-->1997	700	ISO 46
1.8	1995-97	700	ISO 100
1.8	1996-97	700	ISO 46
1.8-TS	-->1996	700	ISO 46
2	1995-97	700	ISO 100
2,0T-4x4	-->1996	700	ISO 46
2.5-TD	-->1997	700	ISO 150
2.5-V6	-->1996	700	ISO 46
	1994-97	700	ISO 46
<b>ALFA ROMEO 156</b>			
1.6-16V-TS		500	ISO 46
1.6-16V-TS		650	ISO 100
1.8-16V-TS		500	ISO 46
1.8-16V-TS		650	ISO 100
1.9-JTD		500	ISO 46
1.9-JTD-16V		500	ISO 46
1.9-ITD	97-01	650	ISO 100
2-16V-TS		500	ISO 46
2-16V-TS		650	ISO 100

2.4-JTD	97-01	650	ISO 100
2.4-JTD		500	ISO 46
2.4-JTD-20V		500	ISO 46
2.4-JTS		500	ISO 46
2.5-V6		500	ISO 46
2.5-V6-24V		650	ISO 100
3.2-GTA		500	ISO 46

### ALFA ROMEO 159

1800-16V-(SW)		550	ISO 46
1800-PFI-(BZ)		500	ISO 46
1900-JTD-(SW)		550	ISO 100
1900-JTD-16V		500	ISO 46
1900-JTD-16V		550	ISO 100
1900-JTD-8V		500	ISO 46
1900-JTS-(SW)		550	ISO 46
1900-L850-(BZ)		500	ISO 46
2200-JTS-(SW)		550	ISO 46
2200-L850-(BZ)		500	ISO 46
2400-JTD		500	ISO 46
2400-JTD-20V		550	ISO 100
3200-HF-V6(BZ)		500	ISO 46
3200-JTS-(SW)		550	ISO 46

### ALFA ROMEO 164

	1994-98	1200	ISO 100
--	---------	------	---------

### ALFA ROMEO 166

2-16V-TS	03->	700	ISO 46
2-16V-TS		700	ISO 46
2-V6-T		700	ISO 46
2.4-JTD	03->	700	ISO 46
2.4-JTD	98-03	700	ISO 46
2.4-JTD-20V		700	ISO 46
2.5-24V-V6	03->	700	ISO 46
2.5-24V-V6		700	ISO 46
2000-16V-TS		500	ISO 46
2000-JTS		500	ISO 46
2400-JTD		500	ISO 46
2400-JTD-20V		500	ISO 46
2500-24V-V6		500	ISO 46
3-24V-V6	03->	700	ISO 46
3-24V-V6		700	ISO 46
3.2-24V-V6	03->	700	ISO 46
3000-24V-V6		500	ISO 46
3200-V6		500	ISO 46

### ALFA ROMEO BRERA

2.2-JTS		550	ISO 100
2.4-JTD-20V		550	ISO 100
3.2-JTS-24V		550	ISO 100
	2006-->	460	ISO 46

### ALFA ROMEO GT

1800-16V-TS		500	ISO 46
1900-JTD		500	ISO 46
2000-JTS		500	ISO 46
3200-GTA		500	ISO 46

### ALFA ROMEO GTV

1.8-16V-TS		650	ISO 46
1800-16V-TS		500	ISO 46
1900-JTD		500	ISO 46
2-16V-TS		700	ISO 100
2-JTS		700	ISO 100
2-V6-T		700	ISO 46
2000-JTS		500	ISO 46
3-V6-24V		700	ISO 46
3.2-V6-24V		700	ISO 46
3200-GTA		500	ISO 46

### ALFA ROMEO GTV/SPIDER

2000-16V-TS		550	ISO 46
2000-JTS		550	ISO 46
3000-V6		550	ISO 46

### ALFA ROMEO SPIDER

1.8-16V-TS		650	ISO 46
2-16V-TS		700	ISO 100
2-JTS	03-05	700	ISO 100
2-V6-T95-00		700	ISO 46
2.2-JTS		550	ISO 100
2.4-JTDm-2007		550	ISO 100
3-V6-24V		700	ISO 46
3.2-JTS-Q4		550	ISO 100
3.2-V6-24V		700	ISO 46

## AUDI

### AUDI 100

Denso	-->1994	800	ISO 46
Zexel	-->94	800	ISO 46
	-->1997	800	ISO 46
	-->92	1150	

### AUDI 80

2.3	-->1994	800	ISO 46
2.3	-->92	950	

### AUDI A2

1,4i	99-05	550	ISO 46
1.2-TDi	99-05	550	ISO 46
1.4-TDi	99-05	550	ISO 46
1.6-FSi	02-05	550	ISO 46
	2000-->	525	ISO 46

### AUDI A3

(TT)-BZ	2003-->	800	ISO 46
1,6i	98-01	700	ISO 46
1,8i	96-03	800	ISO 46

1.8-T	96-00	700	ISO 46
1.9-TDI	2003-->	525	ISO 46
1.9-TDI	96-03	800	ISO 46
1.9-TDI		800	ISO 46
2-TDI	2003-->	525	ISO 46
2-TDI-4	2003	800	ISO 46
	1996-02	800	ISO 46
	2003-->	550	ISO 46

#### AUDI A3(APF-AVU-BFQ)

1,6i	98-03	800	ISO 46
------	-------	-----	--------

#### AUDI A3(ARY-AUM-AUQ)

1.8-T	00-03	750	ISO 46
-------	-------	-----	--------

#### AUDI A4

-(BZ)	02-04	500	ISO 46
-(DS)	02-04	500	ISO 46
-DS	04-->	500	ISO 46
-Denso	01-02	700	ISO 46
-Denso	04-->	700	ISO 46
-Denso	94-01	700	ISO 46
-Denso-AWG	01-02	600	ISO 46
-Denso-AWG	04-->	600	ISO 46
-Denso-AWG	94-01	600	ISO 46
-Dn-Showa	01-02	750	ISO 46
-Dn-Showa	04-->	750	ISO 46
-Dn-Showa	94-01	750	ISO 46
-Zex-Showa	01-02	750	ISO 46
-Zex-Showa	04-->	750	ISO 46
-Zex-Showa	94-01	750	ISO 46
-Zexel	01-02	700	ISO 46
-Zexel	04-->	700	ISO 46
-Zexel	94-01	700	ISO 46
-Zexel-AWG	01-02	600	ISO 46
-Zexel-AWG	04-->	600	ISO 46
-Zexel-AWG	94-01	600	ISO 46
-cond-AWG	1998	600	ISO 46
cond-SHOWA	97-02	750	ISO 46
	1994-97	700	ISO 46
	2001-04	520	ISO 46
	2004-->	460	ISO 46

#### AUDI A5

3,0Tdi-V6-4	07>	600	
4.2-V8-Q4	07-->	600	

#### AUDI A6

-Denso	1994-97	775	ISO 46
-Denso	1998	875	ISO 46
-Denso-16mm	1998	575	ISO 46
-Denso18mm	99-00	675	ISO 46
-Zexel	1994-97	775	ISO 46

-Zexel	1998	875	ISO 46
-Zexel-16mm	1998	575	ISO 46
-cond-16MM	1998	600	ISO 46
-cond-18MM	99-02	700	ISO 46
-cond-20MM	98-99	800	ISO 46
2	1999-04	600	ISO 46
3	1999-04	600	ISO 46
3-(BBJ)-Denso		700	ISO 46
3-(BBJ)-Zexel		700	ISO 46
BZ	2004-->	530	ISO 46
Denso-18mm	99-00	675	ISO 46
Denso-20mm	98-99	775	ISO 46
V8	1998-99	600	ISO 46
V8	1999-02	700	ISO 46
Zexel-18mm	99-00	675	ISO 46
Zexel-20mm	98-99	775	ISO 46
	1998	900	ISO 46
	1999-04	700	ISO 46
	2004-->	550	ISO 46

### AUDI A6 Diesel

-Denso	1997	825	ISO 46
-Denso	97-98	875	ISO 46
-Denso-16mm	1998	575	ISO 46
-Zexel	1997	825	ISO 46
-Zexel	97-98	875	ISO 46
-Zexel-16mm	1998	575	ISO 46
DS	2004-->	530	ISO 46
Denso-20mm	98-99	775	ISO 46
Zexel-18mm	99-00	675	ISO 46
Zexel-20mm	98-99	775	ISO 46
	2003-04	700	ISO 46

### AUDI A8

-Denso	1994-97	775	ISO 46
-Denso	1997-01	825	ISO 46
-Zexel	1994-97	775	ISO 46
-Zexel	1997-01	825	ISO 46
	1994-97	800	ISO 46
	1997-02	850	ISO 46
	2002-->	620	ISO 46

### AUDI A8 Diesel

-Denso	1997-02	825	ISO 46
-Denso	2002-->	825	ISO 46
-Zexel	1997-02	825	ISO 46
-Zexel	2002-->	825	ISO 46
	2002-->	620	ISO 46

### AUDI ALLROAD

2.5-Tdi	2000-05	700	ISO 46
2.7-Bt.	2000-->	700	ISO 46
4.2-Avant-Denso		700	ISO 46

4.2-Avant-Zexel		700	ISO 46
<b>AUDI AVANT RS2</b>			
	1994-95	800	ISO 46
<b>AUDI CABRIO</b>			
2.3	-->1994	800	ISO 46
	-->2000	700	ISO 46
	-->92	750	
<b>AUDI COUPE</b>			
2.3	-->1994	800	ISO 46
S2	-->1996	800	ISO 46
	-->1996	700	ISO 46
<b>AUDI Q7</b>			
3-TDI	2006->	700	
3-TDI-6(EV)		1050	
3.6-FSI	2007->	700	
3.6-FSI-7(EV)		1050	
4.2-FSI	2006->	700	
4.2-FSI-6(EV)		1050	
4.2-TDI	2007->	700	
4.2-TDI-7(EV)		1050	
	2006->	1050	
<b>AUDI RS4</b>			
2,7T-AWG	1998	550	
2,7T-Showa	97	700	
2.7-T	94-97	650	
<b>AUDI RS6</b>			
4.2	2003-05	575	
<b>AUDI S2</b>			
2.2-Turbo	92-96	900	ISO 46
RS2-Avant4	94->	700	ISO 46
<b>AUDI S3</b>			
2-TFSI	2006->	525	ISO 46
	1996-02	800	ISO 46
<b>AUDI S4</b>			
-Den-Showa	97-00	750	ISO 46
-Denso-AWG	97-00	600	ISO 46
-Zex-Showa	97-00	750	ISO 46
-Zexel-AWG	97-00	600	ISO 46
AWG	1998	600	ISO 46
SHOWA	1997-02	750	ISO 46
	1994-97	700	ISO 46
	2003-05	500	ISO 46
<b>AUDI S6</b>			
-Den.-18mm	99-04	675	ISO 46
-Denso	1994-97	775	ISO 46
-Denso	99-04	575	ISO 46
-Zex.-18mm	99-04	675	ISO 46
-Zexel	-->1997	775	ISO 46

-Zexel	99-04	575	ISO 46
	-->1997	800	ISO 46
<b>AUDI S8</b>			
	1996-02	850	ISO 46
	2002-->	640	ISO 46
<b>AUDI TT</b>			
-cond-16MM	98-04	670	ISO 46
-cond-20MM	98-04	800	ISO 46
	1998-02	800	ISO 46
	2007-->	525	
<b>BMW</b>			
<b>BMW 750iL</b>			
-(2EV)	1994-->	1400	ISO 46
	1994-->	1270	ISO 46
<b>BMW M3</b>			
E36-Denso	92-99	850	
E36-Seiko	92-99	1000	
E46-Seiko	00-05	750	
<b>BMW M5</b>			
E39	98-03	750	
E60	2005-->	700	
<b>BMW MZ3</b>			
E36-t.p.	94-02	850	
E36-t.t.	94-02	1000	
<b>BMW Serie 1</b>			
N45/N46/M47	04-->	515	
<b>BMW Serie 3</b>			
E30	83-88	800	
E36-Denso	95-00	850	
E36-Seiko	95-00	1000	
E46	2001-->	760	
E46DIESEL	2001-->	680	
E90	2005-->	500	
E90	2005-->	600	
E91	2005-->	600	
E91-SW	2005-->	500	
E92-Cabrio	2005	500	
<b>BMW Serie 5</b>			
E34	-->1996	1500	ISO 46
E34-t.p.	88-96	1450	
E34-t.t.	88-96	1550	
E39	1996-98	1250	
E39	1998-02	760	
E39	95-04	750	
E39-520d	00-03	680	
E39-525td	97-04	750	
E39-530d	98-04	680	
E60	2003-->	700	

E60	2003-->	820	
E60-D	2003-->	710	
E61	2003-->	820	
E61	2004-->	700	
E61-D	2003-->	710	
<b>BMW Serie 5 (2EV)</b>			
E39	95-04	1250	
E39-525td	97-04	1250	
<b>BMW Serie 6</b>			
E63	2004-->	820	
E64	2004-->	820	
<b>BMW Serie 7</b>			
E32	-->1994	1575	
E32	1986-92	1950	
E38	1994-98	1235	
E38	1998-02	690	
E65	2005-->	820	
E66	2005-->	730	
<b>BMW Serie 7 (2EV)</b>			
E32	-->1994	1725	
E32	1986-92	2100	
<b>BMW Serie 8</b>			
E31	-->1999	1575	
<b>BMW X3</b>			
E83	2004-06	750	
E83-D	2004-06	690	
<b>BMW X5</b>			
E53	1999-->	450	
<b>BMW Z3</b>			
COND.DENSO	1997	850	ISO 46
E36-t.p.	94-02	850	
E36-t.t.	94-02	1000	
	1997-->	1000	ISO 46
	1997-02	1025	
<b>BMW Z4</b>			
E85--	2003-->	740	
<b>BMW Z8</b>			
E62	2000-->	710	ISO 46
<b>CHEVROLET</b>			
<b>CHEVROLET CAPTIVA</b>			
	2006-->	610	
	2007-->	520	
<b>CHEVROLET EPICA</b>			
	2006-->	820	
<b>CHEVROLET EVANDA</b>			
-T20SED	2004-->	730	ISO 150
<b>CHEVROLET KALOS</b>			
	01.05-06	645	

	2004-->	600	ISO 150
<b>CHEVROLET LACETTI</b>			
	01.05-06	630	
	2004-->	620	ISO 150
<b>CHEVROLET MATIZ</b>			
	01.05-06	330	
	2004-05	500	ISO 46
<b>CHEVROLET NUBIRA</b>			
	01.05-06	645	
	2004-->	620	ISO 150
<b>CHEVROLET REZZO</b>			
	01.05-06	700	
<b>CHEVROLET TACUMA/REZZO</b>			
	2004-->	750	
<b>CHRYSLER</b>			
<b>CHRYSLER 300C</b>			
	2005-->	737	ISO 100
<b>CHRYSLER 300M</b>			
	1998-05	710	ISO 100
<b>CHRYSLER CHEROKEE</b>			
2.5-CRD	2001-->	737	ISO 46
2.8-CRD	2001-->	625	
3.1-TD	00-01	600	ISO 100
Diesel	1994-95	900	ISO 100
	1994-96	900	ISO 100
	1997-05	550	ISO 100
<b>CHRYSLER CROSSFIRE</b>			
	2004-->	880	
	2005-->	850	
<b>CHRYSLER GRAN CHEROKEE</b>			
	1994-->	795	ISO 46
	1998-->	737	ISO 46
	2000-->	680	ISO 46
	2002-->	765	ISO 46
	2004-->	760	ISO 46
	2005-->	680	ISO 46
<b>CHRYSLER LE BARON</b>			
	1994-->	737	ISO 46
<b>CHRYSLER NEON</b>			
	1994-->	820	ISO 46
	1997-->	784	ISO 46
	1999-->	850	ISO 46
	2000-->	765	ISO 46
<b>CHRYSLER PT CRUISER</b>			
-CABRIO	2005-->	510	ISO 46
-CRD	2002-->	595	ISO 46
	2001-->	710	ISO 46
<b>CHRYSLER SEBRING</b>			

-CABRIO	2001-->	765	ISO 46
-CABRIO	2002-->	570	ISO 46
-CABRIO	2003-->	640	ISO 46
-TURBO	2001-->	500	ISO 46

### CHRYSLER STRATUS

-CABRIO	1997-->	795	ISO 46
-CABRIO	1999-->	570	ISO 46
-CABRIO	2000-->	540	ISO 46
	1995-->	795	ISO 46
	1997-->	737	ISO 46
	1999-->	574	ISO 46

### CHRYSLER VIPER

	1995-->	850	ISO 46
	2004-->	454	ISO 46

### CHRYSLER VISION

	1994-->	794	ISO 46
--	---------	-----	--------

### CHRYSLER VOYAGER/GRAND V

1-EVAP	1995-00	950	ISO 46
1-EVAP	2003-06	960	ISO 46
2-EVAP	1995-00	1350	ISO 46
2-EVAP	2003-06	1360	ISO 46

### CHRYSLER WRANGLER

	1994-->	900	
	1996	567	ISO 46

### CITROEN

#### CITROEN AX

	-->1997	650	ISO 100
--	---------	-----	---------

#### CITROEN BERLINGO

	1996-02	900	ISO 46
--	---------	-----	--------

#### CITROEN BERLINGO Diesel

	1999-02	800	ISO 46
--	---------	-----	--------

#### CITROEN BERLINGO II

	12/2002-->	575	ISO 46
--	------------	-----	--------

#### CITROEN C1

Mot.384/F	2005>	450	ISO 46
Mot.DV4TD	2005>	500	ISO 46

#### CITROEN C2

	-->07-04	625	ISO 46
	07/2004-->	500	ISO 46

#### CITROEN C3/C3 Pluriel

	-->07-04	625	ISO 46
	07/2004-->	500	ISO 46

#### CITROEN C4

	-->10/2005	680	ISO 46
	10/2005-->	470	ISO 46

#### CITROEN C4 PICASSO

-EW10A	10/2006>	450	ISO 46
-EW7A	10/2006>	450	ISO 46

DV6TED4	10/2006>	450	ISO 46
DW10BTED4	2006->	450	ISO 46
<b>CITROEN C4 PICASSO(2EV)</b>			
DW10BTED4	2006->	450	ISO 46
<b>CITROEN C5</b>			
DW12B	07/2006->	525	ISO 46
DW12B	09/2004->	625	ISO 46
<b>CITROEN C6</b>			
DT17	12/2005-->	525	ISO 46
DW12B	12/2005->	525	ISO 46
ES9A	12/2005-->	625	ISO 46
<b>CITROEN C8</b>			
	06/2001>	600	ISO 46
<b>CITROEN EVASION</b>			
	1994-02	1000	ISO 46
<b>CITROEN JUMPER</b>			
(2EV)	10/2004-->	700	
(2EV)	10/2006-->	950	
D	2002-->	800	ISO 100
	10/2004-->	500	
	10/2006-->	550	
	1994-96	1050	ISO 100
	1996-02	850	ISO 100
<b>CITROEN JUMPER (2EV)</b>			
D	2002-->	1000	ISO 100
	1994-96	1250	ISO 100
	1996-02	1050	ISO 100
<b>CITROEN JUMPY II</b>			
	12/2003-->	950	
<b>CITROEN PICASSO</b>			
DS	2000-->	700	ISO 46
	2000-->	700	ISO 46
<b>CITROEN SAXO</b>			
	1996	625	ISO 46
	1996-03	775	ISO 46
	1997-02	800	ISO 46
<b>CITROEN XANTIA</b>			
1,9D	1996-01	850	ISO 150
1,9TD	1996-01	850	ISO 150
16MM	-->2001	900	ISO 46
23MM	-->2001	1000	ISO 46
3	1997-01	725	ISO 46
	-->2001	800	ISO 100
<b>CITROEN XANTIA BZ</b>			
3,0i	96-01	725	ISO 46
SD-SB16	93-01	900	ISO 46
SD-SH15	93-01	800	ISO 100
<b>CITROEN XANTIA DS</b>			

Delphi	93-01	825	ISO 150
SD-7H 15	93-01	775	ISO 100
<b>CITROEN XANTIA DS 16Ti</b>			
SD-7V-16	93-01	875	ISO 46
<b>CITROEN XANTIA DS 23TR</b>			
SD-7V-16	93-01	975	ISO 46
<b>CITROEN XM</b>			
2,5D	1994-96	850	ISO 100
2,5D	1996-01	850	ISO 46
3	-->2001	750	ISO 46
DS	-->1996	725	ISO 46
DS	1996-->	725	ISO 100
	-->1996	750	ISO 100
	1996-01	750	ISO 46
<b>CITROEN XSARA</b>			
BZ-SD7V12	97-98	975	ISO 46
BZ-SD7V12	99-00	725	ISO 46
BZ-SD7V16	97-98	975	ISO 46
D	1997-02	900	ISO 46
DS-SD7V12	99-00	700	ISO 46
DS-SD7V16	97-98	875	ISO 46
<b>CITROEN XSARA PICASSO</b>			
-DV6TED4	2004-->	625	ISO 46
-EW7J4	->12/2002	710	ISO 46
-EW7J4	12/2002->	650	ISO 46
-TU5JP	->12/2002	710	ISO 46
-TU5JP	12/2002->	650	ISO 46
BRASIL		775	ISO 46
DW10TD	->12/2002	650	ISO 46
DW10TD	->12/2002	675	ISO 46
EW10J4	->12/2002	650	ISO 46
EW10J4	->12/2002	775	ISO 46
<b>CITROEN ZX</b>			
	-->1998	950	ISO 100
<b>DACIA</b>			
<b>Dacia Logan</b>			
	2004-->	850	ISO 46
	2006-->	550	
<b>DAEWOO</b>			
<b>DAEWOO EPICA</b>			
	2006-->	820	
<b>DAEWOO ESPERO</b>			
	-->2000	750	
<b>DAEWOO EVANDA</b>			
	2003-->	740	
<b>DAEWOO KALOS</b>			
	2002-4	550	
	2005->	600	ISO 150

<b>DAEWOO KORANDO</b>			
	1996-00	700	
<b>DAEWOO LANCETTI</b>			
-(GD)	2004-->	680	ISO 150
	2004-->	640	ISO 150
<b>DAEWOO LANOS</b>			
	1997-02	720	ISO 150
	2001-02	750	ISO 150
<b>DAEWOO LEGANZA</b>			
	1997-02	820	ISO 150
<b>DAEWOO MATIZ</b>			
	1998-05	550	ISO 46
<b>DAEWOO MUSSO</b>			
	1996-00	700	ISO 100
<b>DAEWOO NEXIA</b>			
	1994-97	750	ISO 150
<b>DAEWOO NUBIRA</b>			
	1997-02	750	ISO 150
<b>DAEWOO NUBIRA 2</b>			
	2003-05	640	ISO 150
<b>DAEWOO REZZO</b>			
	2000-->	750	ISO 150
<b>DAEWOO TACUMA</b>			
-GD	2001-05	850	ISO 150
	2001-05	750	ISO 150
<b>DAEWOO AVIA</b>			
<b>DAEWOO AVIA D60</b>			
DS-3.9	2000-05	850	
<b>DAEWOO AVIA D75</b>			
DS-3.9	2000-07	850	
<b>DAEWOO AVIA D90</b>			
DS-3.9	2000-07	850	
<b>DAF</b>			
<b>DAF 430/AAF</b>			
		700	
<b>DAF 45</b>			
	1996-01	1000	
<b>DAF 65</b>			
	-->1993	850	
<b>DAF 75</b>			
	-->1993	900	
<b>DAF 85</b>			
	-->1993	900	
<b>DAF 95</b>			
	-->1993	1000	
<b>DAF 95 XF</b>			
	1997-03	700	
<b>DAF CF 65</b>			

	2001-04	850	
<b>DAF CF 75</b>			
	2001-04	850	
<b>DAF CF 85</b>			
	2001-04	850	
<b>DAF LF 45</b>			
	2001-04	1000	
<b>DAF LF 55</b>			
	2001-04	1000	
<b>DAF XF 95</b>			
	2002-06	700	
<b>DAIHATSU</b>			
<b>DAIHATSU CUORE</b>			
-L701	1998-->	380	ISO 46
	2003-->	380	ISO 46
<b>DAIHATSU CUORE 2</b>			
-L251	2003-->	400	
<b>DAIHATSU GRAN MOVE</b>			
-G301	1996-->	650	
-G301	1998-->	400	
-G303	1996-->	550	
<b>DAIHATSU MOVE</b>			
-L901	1996-->	380	
<b>DAIHATSU SIRION</b>			
-M100	1998-->	400	
-M101	1998-->	360	
-M111	1998-->	360	
-MOT.EJ	2000-->	380	
-MOT.EK	2000-->	340	
	2005-->	300	
<b>DAIHATSU TERIOS</b>			
-J100	1997-->	600	
-J102	1997-->	400	
J100J102	1998-->	400	
<b>DAIHATSU YRV</b>			
M201,M211	2001->	380	
	2001-->	400	
<b>FERRARI</b>			
<b>FERRARI 348 GTB</b>			
	1994-->	900	
<b>FERRARI 348 GTS</b>			
	1994-->	900	
<b>FERRARI 348 TB</b>			
	1994-->	900	
<b>FERRARI 348 TS</b>			
	1994-->	900	
<b>FERRARI 360 F1 MODENA</b>			
	1999-->	750	

<b>FERRARI 360 MODENA</b>			
	1999-->	750	
<b>FERRARI 456 GT</b>			
	1994-->	800	
<b>FERRARI 456 GTA</b>			
	1996-->	800	
<b>FERRARI 550 MARANELLO</b>			
	1996-->	900	
<b>FERRARI F355 BERLINETTA</b>			
TB	1994-->	800	
<b>FERRARI F355 F1 BERLIN.</b>			
	1994-->	800	
<b>FERRARI F355 F1 GTS</b>			
	1994-->	800	
<b>FERRARI F355 F1 SPIDER</b>			
	1995-->	800	
<b>FERRARI F355 GTS</b>			
	1994-->	800	
<b>FERRARI F355 SPIDER</b>			
	1995-->	800	
<b>FIAT</b>			
<b>FIAT 500</b>			
	2007-->	470	ISO 46
<b>FIAT BARCHETTA</b>			
1750		550	ISO 100
<b>FIAT BRAVO/A</b>			
-DENSO	(->01)	650	ISO 100
-HARRISON	(->01)	650	ISO 150
100-TD		500	ISO 100
1242-16V		500	ISO 46
1580-16V		500	ISO 100
1800-16V-(ND)		500	ISO 100
1800-16V-(SD)		500	ISO 46
1910-JTD		500	ISO 46
2000-HGT		500	ISO 100
75-TD		500	ISO 100
	2007-->	500	ISO 46
<b>FIAT CINQUECENTO</b>			
	-->1997	700	ISO 46
<b>FIAT COUPE</b>			
4-cilindri		730	ISO 100
5-cilindri		500	ISO 100
<b>FIAT CROMA</b>			
-(BZ)	(92-96)	1100	ISO 100
-(DS)	(92-96)	1100	ISO 100
1.9-JTD-16V		730	ISO 46
1.9-JTD-8V		730	ISO 46
1800-16V-(BZ)		730	ISO 46

2.4-JTD-20V		800	ISO 46
2200-16V-(BZ)		730	ISO 46
<b>FIAT DOBLO"</b>			
1242-16V		600	ISO 46
1242-8V		600	ISO 46
1600-16V		600	ISO 46
1800-G.M.		600	ISO 46
1910-DIESEL		600	ISO 46
1910-JTD		600	ISO 46
TT		650	ISO 46
<b>FIAT DOBLO" RESTY</b>			
01:02-MULTIJET		475	ISO 46
01:04-FIRE-BZ		475	ISO 46
01:06-TORQUE-BZ		475	ISO 46
1910-JTD		475	ISO 46
<b>FIAT DUCATO 250</b>			
IVECO-2300-JTD		550	ISO 46
IVECO-3000-JTD		550	ISO 46
PUMA-2.2TD-HDI		550	ISO 46
<b>FIAT DUCATO 250 PULM</b>			
IVECO-2300-JTD		950	ISO 46
IVECO-3000-JTD		950	ISO 46
PUMA-2.2TD-HDI		950	ISO 46
<b>FIAT DUCATO F.L.025</b>			
2000-BZ-SD7V16		500	ISO 46
2000-JTD-SD7V16		500	ISO 46
2200-JTD-SD7V16		500	ISO 46
2300-JTD-SD7V16		500	ISO 46
2800-JTD-SD7H15		500	ISO 100
<b>FIAT DUCATO F.L.204</b>			
2000-BZ-SD7V16		700	ISO 46
2000-JTD-SD7V16		700	ISO 46
2200-JTD-SD7V16		700	ISO 46
2300-JTD-SD7V16		700	ISO 46
2800-JTD-SD7H15		700	ISO 100
<b>FIAT DUCATO OPT 025</b>			
1905		800	ISO 100
2000-BZ		800	ISO 100
2000-BZJ		800	ISO 100
2500-AJ5		800	ISO 100
2800-SOFIM		800	ISO 100
<b>FIAT DUCATO OPT 204</b>			
1905		950	ISO 100
2000-BZ		950	ISO 100
2000-BZJ		950	ISO 100
2500-AJ5		950	ISO 100
2800-SOFIM		950	ISO 100
<b>FIAT GRANDE PUNTO</b>			

1242-8V-(BZ)		500	ISO 46
1248-JTD-(70CV)		500	ISO 46
1248-JTD-(90CV)		500	ISO 46
1372-8-16V-(BZ)		500	ISO 46
1910-JTD-(70CV)		500	ISO 46
<b>FIAT IDEA</b>			
1242-16V-(BZ)		500	ISO 46
1250-DS-16V		500	ISO 46
1400-16V-(BZ)		500	ISO 46
1910-DS-8V		550	ISO 46
<b>FIAT IDEA BRASILE</b>			
1400-8V		625	ISO 46
1800-8V		450	ISO 150
<b>FIAT MAREA</b>			
1242-16V		600	ISO 46
1580-16V		600	ISO 100
1800-16V-(ND)		600	ISO 100
1800-16V-(SD)		600	ISO 46
1910-JTD		600	ISO 46
2000-HGT		600	ISO 100
2400-JTD		600	ISO 46
75-TD		600	ISO 100
<b>FIAT MULTIPLA</b>			
1580-16V		450	ISO 150
1910-JTD		450	ISO 46
BPOWER-1580-16V		450	ISO 150
	2004-->	650	ISO 100
<b>FIAT PALIO BIPOWER</b>			
ALL-TYPE		625	ISO 46
<b>FIAT PALIO/SIENA</b>			
1242		625	ISO 46
1580-16V		625	ISO 46
1697-TD		625	ISO 46
TT		750	
<b>FIAT PANDA</b>			
01:00-BZ		500	ISO 46
1.2-BZ		500	ISO 46
1.3-JTD		500	ISO 46
	-->1999	700	ISO 46
	1999-03	750	ISO 46
<b>FIAT PUNTO I (176)</b>			
	-->1999	675	ISO 100
<b>FIAT PUNTO II (188)</b>			
1.9-JTD-(100CV)		550	ISO 46
1.9-JTD-(85CV)		550	ISO 46
1242-8-E16V		500	ISO 46
1248-JTD		500	ISO 46
1372-8-E16V		500	ISO 46

1750-16V-(BZ)		550	ISO 46
<b>FIAT PUNTO II (P.2)</b>			
1.9-JTD-2003->		650	ISO 100
	2003->	550	ISO 100
<b>FIAT SCUDO</b>			
-PULMAN	2006-->	950	
	1995-02	1000	ISO 46
	2006-->	550	
<b>FIAT SEDICI</b>			
	2006-->	430	ISO 46
<b>FIAT SEICENTO</b>			
-176	1998-->	500	ISO 46
-187	1998-->	525	ISO 46
<b>FIAT STILO</b>			
1242-16V		500	ISO 46
1545-16V		500	ISO 46
1747-16V		500	ISO 46
1910-JTD		500	ISO 46
2400-20V		500	ISO 46
<b>FIAT STRADA</b>			
BENZINA	1999-->	750	
DIESEL	1999-->	750	
<b>FIAT TEMPRA</b>			
(Sanden)	1994-97	730	ISO 46
-(V5)	1994-97	730	ISO 150
<b>FIAT TIPO</b>			
(Sanden)	1994-95	730	ISO 46
-(V5)	1994-95	730	ISO 150
<b>FIAT ULYSSE</b>			
--121	1994-02	1000	ISO 46
--179	2002-->	625	ISO 46
<b>FORD</b>			
<b>FORD COUGAR</b>			
	1994-98	750	ISO 46
<b>FORD COURIER</b>			
	1996-00	750	ISO 46
<b>FORD ESCORT</b>			
-(ALL)	1994-01	750	ISO 46
<b>FORD FIESTA</b>			
	1994-02	750	ISO 46
<b>FORD FIESTA 3</b>			
-(ALL)	1995-02	750	ISO 46
<b>FORD FIESTA 4</b>			
1.6-TD	2002-07	520	ISO 46
	2002-07	650	ISO 46
<b>FORD FOCUS</b>			
	1998-03	750	ISO 46
	2004-->	615	ISO 46

	2005-->	615	ISO 46
<b>FORD FOCUS C MAX</b>			
-C.1,2mm	2003-07	600	ISO 46
-C.3mm	2003-07	740	ISO 46
<b>FORD FUSION</b>			
	2005-->	650	ISO 46
<b>FORD GALAXI</b>			
-(2EV)	1995-00	1400	ISO 46
-(2EV)	2000-06	1100	ISO 46
-(2EV)	2006-->	850	ISO 46
1,9TDI	1995-00	1000	ISO 46
1,9TDI	2000-01	750	ISO 46
2,0/2,3	2000-02	750	ISO 46
2.8	1995-00	1000	ISO 46
2.8	2000-01	750	ISO 46
	1995-00	1000	ISO 46
	2000-06	750	ISO 46
	2006-->	600	ISO 46
	2007-->	600	ISO 46
<b>FORD GALAXY (2EV)</b>			
1,9TD	1995-00	1400	ISO 46
1,9TD	2000-02	1100	ISO 46
2.8	1995-00	1400	ISO 46
2.8	2000-02	1100	ISO 46
	2007-->	850	ISO 46
<b>FORD KA</b>			
-(ALL)	1996-->	650	ISO 46
	2003-->	665	ISO 46
<b>FORD MAVERICK</b>			
	2001-04	850	ISO 46
<b>FORD MONDEO</b>			
-COND.1,2MM	2000	700	ISO 46
B4Y-C.1,2MM	00>	700	ISO 46
B4Y-C.3,0MM	00>	820	ISO 46
B5Y-C.1,2MM	00>	700	ISO 46
B5Y-C.3,0MM	00>	820	ISO 46
BAP/BFP/BNP	96->	740	ISO 46
BWY-C.1,2MM	00>	700	ISO 46
BWY-C.3,0MM	00>	820	ISO 46
	-->1999	740	ISO 46
	2000-->	820	ISO 46
	2007-->	590	
<b>FORD PROBE</b>			
	-->1997	1000	ISO 46
	1994-98	1165	ISO 46
<b>FORD PUMA</b>			
	1997-02	750	ISO 46
<b>FORD RANGER</b>			

-(BZ)	1999-05	550	ISO 100
-(DS)	1999-07	550	ISO 46
	1999-02	550	ISO 46
<b>FORD S-MAX</b>			
-(2EV)	2007-->	850	ISO 46
	2007-->	615	ISO 46
<b>FORD SCORPIO</b>			
-(ALL)	-->1998	1000	ISO 46
	1994	650	ISO 46
	1994-98	1020	ISO 46
<b>FORD SIERRA</b>			
-(ALL)	1982-93	750	ISO 46
<b>FORD STREET-KA</b>			
	2003-->	665	ISO 46
<b>FORD TRANSIT</b>			
-(2EV)	1994-8/97	1200	ISO 46
-(2EV)	2000-06	1700	ISO 46
-(2EV)	2006-->	1400	ISO 46
-(2EV)	8/97-99	1400	ISO 46
-FRIGO	2000-06	2650	ISO 46
	1994-00	900	ISO 46
	1994-00	915	ISO 46
	2000-02	760	ISO 46
	2000-06	990	ISO 46
	2002-->	1100	ISO 46
	2006-->	750	ISO 46
<b>FORD TRANSIT (2EV)</b>			
	1994-97	1425	ISO 46
	1997-00	1225	ISO 46
	2000-02	1590	ISO 46
	2002-->	1730	ISO 46
<b>FORD TRANSIT CONNECT</b>			
-(2EV)	2004-->	1400	ISO 46
	2004-->	750	ISO 46
<b>FORD TRANSIT R. LONG</b>			
	2002-->	2990	ISO 46
<b>FORD TRANSIT REFR</b>			
	2002-->	2750	ISO 46
<b>FORD TURNEO CONNECT</b>			
-(2EV)	2002-05	1550	ISO 46
	2002-05	750	ISO 46
<b>HONDA</b>			
<b>HONDA ACCORD</b>			
D	1996-98	650	ISO 46
	1994-02	650	ISO 46
	1995-1998	750	ISO 46
	1997-2003	550	ISO 46
	2003-->	550	ISO 46

<b>HONDA ACCORD COUPE</b>			
	1997-2003	650	ISO 46
<b>HONDA CIVIC</b>			
	-->1995	550	ISO 46
	1996-01	650	ISO 46
	2000-02	550	ISO 46
	2004-->	550	ISO 46
<b>HONDA CONCERTO</b>			
	-->1995	800	ISO 46
<b>HONDA CRV</b>			
	1997-02	700	ISO 46
	2004-->	530	ISO 46
<b>HONDA CRX</b>			
-MATSUSHIT	87-98	550	ISO 46
DENSO-SAND	87-98	600	ISO 46
	1994-97	550	ISO 46
<b>HONDA FRV</b>			
	2005-06	580	ISO 46
<b>HONDA HRV</b>			
	1999-02	600	ISO 46
	2000-06	857	ISO 46
<b>HONDA JAZZ</b>			
	2001-05	425	ISO 46
<b>HONDA LEGEND</b>			
	-->1996	800	ISO 46
	1996-02	750	ISO 46
<b>HONDA LOGO</b>			
	1999-02	550	ISO 46
<b>HONDA PRELUDE</b>			
-(V-TEC)	1996-01	750	ISO 46
	-->1996	625	ISO 46
	1994-96	650	ISO 46
	1997-01	750	ISO 46
<b>HONDA S2000</b>			
	2000-02	650	ISO 46
	2003-07	575	ISO 46
<b>HONDA SHUTTLE</b>			
-(2EV)	1995-01	850	ISO 46
	1995-01	650	ISO 46
<b>HONDA STREAM</b>			
-(2EV)	2001-06	750	ISO 46
	2001-06	550	ISO 46
<b>HYUNDAI</b>			
<b>HYUNDAI ACCENT</b>			
	1994-99	650	ISO 46
	1999-->	600	ISO 46
	2001-06	525	ISO 46
<b>HYUNDAI ATOS</b>			

	01.03-06	500	ISO 46
	1998-05	675	ISO 46
<b>HYUNDAI ELANTRA</b>			
	1995-06	700	ISO 46
<b>HYUNDAI EXCEL</b>			
	1989-99	600	ISO 46
<b>HYUNDAI GALLOPPER</b>			
	2000-01	775	ISO 46
<b>HYUNDAI GETZ</b>			
	2002	500	ISO 46
	2003-->	525	ISO 46
<b>HYUNDAI H1</b>			
-COMP-HS15	02-06	675	ISO 46
-COMP-HS18	02-06	975	ISO 46
<b>HYUNDAI H100</b>			
-2-EVAP	2002-->	1450	ISO 46
	2002-->	675	ISO 46
<b>HYUNDAI LANTRA</b>			
	1994	900	
	1994-96	680	ISO 46
	1996-00	725	ISO 46
<b>HYUNDAI MATRIX</b>			
	2001-05	550	ISO 46
<b>HYUNDAI PONY</b>			
	-->1994	700	ISO 46
<b>HYUNDAI S COUPE</b>			
	-->1994	900	
	1994-02	700	ISO 46
	2001-05	650	ISO 46
<b>HYUNDAI SANTA FE</b>			
2.2	2003-->	625	ISO 46
2.7	2003-->	875	ISO 46
	1999-->	600	ISO 46
<b>HYUNDAI SONATA</b>			
	-->1994	825	ISO 46
	1988-93	900	
	1995-97	750	ISO 46
	1998-02	725	ISO 46
<b>HYUNDAI SONICA</b>			
	1994-->	700	ISO 46
<b>HYUNDAI TERRACAN</b>			
	2003-->	875	ISO 46
<b>HYUNDAI TRAJET</b>			
-(2EV)	2000-02	850	ISO 46
	2000-02	670	ISO 46
<b>HYUNDAI TUCSON</b>			
	2004-->	530	ISO 46
<b>HYUNDAI XG</b>			

	1999-02	695	ISO 46
<b>ISUZU</b>			
<b>ISUZU CAMPO DIESEL</b>			
	-->2003	750	ISO 46
<b>ISUZU TF</b>			
2.5-TDI	(02-03)	650	ISO 46
<b>ISUZU TROOPER</b>			
	1998-02	750	ISO 100
<b>ISUZU TROOPER DIESEL</b>			
	1998-02	750	ISO 46
<b>IVECO</b>			
<b>IVECO DAILY</b>			
-COMBI	1999-05	1200	
-COMBI	2003-04	1200	ISO 46
3-td	2006-->	440	ISO 46
	1999-02	750	
	2003-06-->	720	ISO 46
<b>IVECO EUROCARGO</b>			
-(2COND)	2001	1500	
	2001-04	1020	
<b>IVECO EUROSTAR</b>			
	-->2001	1600	
	2000-04	1700	
<b>IVECO EUROTECH</b>			
	-->1999	1700	
	2000-04	1400	
<b>IVECO EUROTRAKKER</b>			
	2000-04	1700	
<b>IVECO STRALIS</b>			
-COND.SOTTO	02>	1400	
	2002-04	700	
<b>IVECO TECTOR</b>			
		1050	
<b>JAGUAR</b>			
<b>JAGUAR DAIMLER</b>			
-4-v8	1994-97	675	ISO 46
6,0-DOU-SIX	-->94	1150	ISO 100
6,0i-XJ12	-->94	1150	ISO 100
<b>JAGUAR S-TYPE</b>			
2.7-DS	2004-->	700	ISO 46
4.2	2002-->	750	ISO 46
BZ	1999-->	800	ISO 46
	2002-->	750	
<b>JAGUAR SOVEREIGN</b>			
-XJ8	1997-03	675	
	-->1994	1150	
	1994-97	1100	ISO 46
<b>JAGUAR X-TYPE</b>			

-BREAK	2004-->	825	
-DS	2003-->	735	ISO 46
	2001-02	825	ISO 46
<b>JAGUAR XJ</b>			
-(2EV)	2003	800	ISO 46
	1981-94	1150	ISO 100
	1998-02	675	ISO 46
	2003	650	ISO 46
<b>JAGUAR XJ12</b>			
6	1994-97	1100	ISO 46
6,0-DOUB-SIX	-->97	1100	ISO 46
	-->1994	1175	ISO 100
	1994-97	1150	ISO 46
<b>JAGUAR XJ6</b>			
3,2V6-24V	97-00	700	
	-->1994	1175	ISO 100
	1986-92	1160	
	1994-97	1150	ISO 46
<b>JAGUAR XJ8</b>			
4,0V8-32V	97-00	700	
	1997-02	700	ISO 100
	2003-->	675	ISO 100
<b>JAGUAR XJR</b>			
-2ZONE	2003-->	650	ISO 46
-4ZONE	2003-->	800	ISO 46
	1994-97	1100	ISO 46
	1994-97	1150	ISO 46
	1997-03	675	
<b>JAGUAR XJS</b>			
	-->1997	950	ISO 100
<b>JAGUAR XK8</b>			
	1996-06	650	
<b>JAGUAR XKR</b>			
	1996-02	700	
	2002-06	650	
<b>JEEP</b>			
<b>JEEP CHEROKEE</b>			
	-->1996	900	
	1997-01	567	ISO 100
	2001-06	737	ISO 46
<b>JEEP GRAND CHEROKEE</b>			
3,1TD	99-05	740	ISO 46
BZ	-->1999	770	ISO 46
DS	-->1999	900	ISO 100
	1999-05	765	ISO 46
	2004-->	765	ISO 46
<b>JEEP WRANGLER</b>			
	-->1996	900	

	1996-97	567	
	1997-01	567	ISO 100
	2001-->	567	ISO 46
<b>KIA</b>			
<b>KIA CARENS</b>			
	1999-02	850	ISO 46
	2000-06	800	
	2006-->	680	ISO 46
<b>KIA CARNIVAL</b>			
2.5-GV6	01-02	1000	ISO 46
	1998-06	1150	ISO 46
	2000-02	1200	ISO 46
<b>KIA CERATO</b>			
DS	2004-->	500	ISO 46
	2004-->	500	ISO 46
<b>KIA CLARUS</b>			
1.8	1996-02	720	ISO 46
2	1996-02	720	ISO 100
<b>KIA JOUCE</b>			
	2000-->	730	ISO 100
<b>KIA K</b>			
2,7i	2000-04	450	ISO 46
<b>KIA MAGENTA</b>			
	2002-->	690	ISO 46
<b>KIA MENTOR</b>			
	1998-04	700	
<b>KIA OPIRUS</b>			
	2003-->	650	
<b>KIA OPTIMA</b>			
	2001-06	680	ISO 46
<b>KIA PICANTO</b>			
DS	2004-->	450	ISO 46
	2004-->	475	
<b>KIA PREGIO</b>			
-12-SEDILI	2001	1150	
-18-SEDILI	2001	1300	
-FURGO	2001-->	800	
<b>KIA RIO</b>			
	2000-05	650	
	2005-->	500	ISO 46
<b>KIA SEPHIA</b>			
	-->1997	700	
	1998-04	700	
<b>KIA SHUMA</b>			
	1998-04	750	ISO 46
<b>KIA SORENTO</b>			
	2002-->	600	ISO 46
	2003-->	625	ISO 46

<b>KIA SPORTAGE</b>			
	1995-01	700	ISO 100
	2000-04	700	ISO 46
	2004-->	510	ISO 46
<b>LAMBORGHINI</b>			
<b>LAMBORGHINI DIABLO</b>			
GT	1999-->	800	
SV	1994-->	800	
SV-ROADSTER	96-->	800	
VT	1994-->	800	
VT-ROADSTER	96-->	800	
<b>LAMBORGHINI GALLARDO</b>			
L-140		550	
<b>LAMBORGHINI GHIBLI</b>			
02:00-PRIMATIST	96-->	850	
2.0I	1995-->	850	
2.0I-CUP	95-->	850	
2.8I	1995-->	850	
<b>LAMBORGHINI GT</b>			
3200-V8	1998-->	850	
<b>LAMBORGHINI MURCIELAGO</b>			
L-147-COUPE		850	
L-148-ROADSTER		850	
<b>LAMBORGHINI QUATTROPORTE</b>			
2.8I-V6	1995-->	900	
3.2I-V8	1995-->	900	
<b>LANCIA</b>			
<b>LANCIA DEDRA</b>			
-DENSO	94-99	700	ISO 100
-HARRISON	1994-->	900	ISO 100
-HARRISON	94-99	700	ISO 150
-SANKYO	-->94	900	ISO 100
-SANKYO	1994-99	700	ISO 100
-SD-710	94-99	700	ISO 100
-SD-7V16	94-99	700	ISO 46
<b>LANCIA DELTA</b>			
-DENSO	94-99	700	ISO 100
-HARRISON	94-99	700	ISO 150
<b>LANCIA DELTA INTEGRALE</b>			
-HARRISON	93-95	800	ISO 150
<b>LANCIA KAPPA</b>			
-D-6CA17	1994-02	800	ISO 46
-SD7V16	1994-02	730	ISO 46
<b>LANCIA LYBRA</b>			
1.6-16V		700	ISO 150
1.6-16V-HRV5		550	ISO 150
1.8-16V		700	ISO 100
1.8-16V-SD7V16		550	ISO 46

1.9-JTD		700	ISO 100
1.9-JTD-SD7V16		550	ISO 46
2-16V-SD6V12		550	ISO 46
2-20V		700	ISO 100
2.4-Bz-SD6V12		550	ISO 46
2.4-JTD		700	ISO 46
2.4-JTD-ND7SB16		550	ISO 46
<b>LANCIA MUSA</b>			
1248-JTD		500	ISO 46
1400-16V-BZ		500	ISO 46
1910-JTD		550	ISO 46
<b>LANCIA PHEDRA</b>			
	2002-->	760	ISO 46
<b>LANCIA THEMA</b>			
	-->1994	1100	ISO 100
	1988-92	1200	
<b>LANCIA THESIS</b>			
2-TBZ-ND7SB16		650	ISO 46
2.4-BZ-C.A.		730	ISO 46
2.4-BZ-ND7SB16		650	ISO 46
2.4-JTD-ND7SB16		650	ISO 46
3-ISUZU		650	ISO 46
3-V6-SD7V16		730	ISO 46
<b>LANCIA Y</b>			
ALL-1997-00		700	ISO 46
<b>LANCIA YPSILON</b>			
1242-16V-SCSB06		500	ISO 46
1242-8V-SCSB06		500	ISO 46
1250-JTD-SCSB06		500	ISO 46
1400-16V-SCSB06		500	ISO 46
<b>LANCIA ZETA</b>			
	1994-02	1000	ISO 46
<b>LAND ROVER</b>			
<b>LAND ROVER DEFENDER</b>			
BZ	-->2004	1100	ISO 46
DS	1999-->	750	ISO 46
	1994-98	1090	ISO 46
	2001-02	930	
	2002-->	800	
<b>LAND ROVER DEFENDER TD5</b>			
	1999-02	800	ISO 46
<b>LAND ROVER DISCOVERY</b>			
-(2EV)	-->98	1150	ISO 46
-(2EV)	1998-04	900	ISO 46
-(2EV)	2004	810	ISO 46
	-->1994	1190	
	-->1998	900	ISO 46
	1998-03	725	ISO 46

	1998-04	700	ISO 46
	2004	550	ISO 46
	2004-->	725	

### LAND ROVER FREELANDER

1.8-16V	00-01	550	ISO 46
1.8-16V	97-00	750	ISO 46
2,0D	1997-03	750	ISO 46
2-TD4	01-04	450	ISO 46
2.5-V6	2001-04	450	ISO 46
	1997-00	750	ISO 46
	2004-->	540	ISO 46

### LAND ROVER RANGE

	-->1994	1080	
	1994-95	900	ISO 46
	1994-98	1250	ISO 46
	1999-02	1450	ISO 46
	2002-->	520	

### LAND ROVER RANGE DIESEL

	1994-02	1100	ISO 46
--	---------	------	--------

### LAND ROVER RANGE ROVER

BZ	-->1996	900	ISO 46
BZ	2002-05	510	ISO 46
BZ	2002-05(2EV)	1400	ISO 46
BZ	96-99	1250	ISO 46
BZ	99-00	1400	ISO 46
DS	-->1996	900	ISO 46
DS	-->2002	1100	ISO 46
DS	2002-05	510	ISO 46
DS	2002-05(2EV)	1100	ISO 46
	2005(EV)-->	810	ISO 46
	2005-->	550	ISO 46

### LDV

#### LDV CUB

	1998-02	625	ISO 46
	1998-02(EV)	675	ISO 46

### LEXUS

#### LEXUS GS 300

	-->1997	850	ISO 46
	1997-->	600	ISO 46
	1998-->	475	ISO 46

#### LEXUS IS 200

DS	2005-->	430	ISO 46
	1999-02	650	ISO 46

#### LEXUS LS 400

-(2EV)	-->94	950	ISO 46
-(2EV)	2000-->	950	ISO 46
	-->1994	700	ISO 46
	1995-00	750	ISO 46

	2000-->	700	ISO 46
<b>LEXUS RX 300</b>			
	2003-->	650	ISO 46
<b>LEXUS RX 400H</b>			
	2003-->	650	ISO 46
<b>LEXUS SC430</b>			
	2001-->	700	ISO 46
<b>LEXUS SPORT CROSS</b>			
	2001-->	650	ISO 46
<b>MAN</b>			
<b>MAN F 2000</b>			
	1995-99	1150	
<b>MAN L 2000</b>			
	1995-99	1250	
<b>MAN M 2000</b>			
	1995-99	1150	
<b>MAN M 90</b>			
	202-04	1300	
<b>MAN TGA</b>			
	2000-04	1150	
<b>MAYBACH</b>			
<b>MAYBACH 0.904761905</b>			
	2002-->	950	
<b>MAZDA</b>			
<b>MAZDA 121</b>			
	-->1995	650	ISO 46
	1996-02	750	ISO 46
<b>MAZDA 2</b>			
-FVS090	99-02	660	ISO 46
-SD6V12	99-02	650	ISO 46
<b>MAZDA 3</b>			
1.6-Y6	2005-->	650	ISO 46
DS-Y6	2003-->	650	ISO 46
	-->2005	500	ISO 46
	2004-->	500	ISO 46
<b>MAZDA 323</b>			
BZ	2000-03	600	ISO 46
DS-1,7-2,0	2003	750	ISO 46
TD-2	1998-03	600	ISO 46
<b>MAZDA 5</b>			
BZ		500	ISO 46
DS	2005-->	500	ISO 46
<b>MAZDA 6</b>			
	2005-->	470	ISO 46
<b>MAZDA 626 (GE)</b>			
BZ	6/94-97	700	ISO 150
DS	-->1997	750	ISO 150
<b>MAZDA 626 (GF-GW)</b>			

BZ	1997-02	650	ISO 46
DS	1997-02	700	ISO 46
<b>MAZDA B-Series</b>			
BZ	1995-->	550	ISO 46
DS	1996-->	550	ISO 46
<b>MAZDA DEMIO</b>			
	1996-03	650	ISO 46
<b>MAZDA E-Series</b>			
-(2EV)	1994-00	1150	ISO 46
	1994-00	550	ISO 46
<b>MAZDA MPV (LV)</b>			
-(2EV)	1994-99	1250	ISO 46
	1994-99	1050	ISO 46
<b>MAZDA MPV (LW)</b>			
-(2EV)	1999-->	850	ISO 46
	1999-->	650	ISO 46
<b>MAZDA MX3</b>			
	1994-98	750	ISO 46
<b>MAZDA MX5</b>			
	1998-->	450	ISO 100
<b>MAZDA MX6</b>			
	1994-98	700	ISO 46
<b>MAZDA PREMACY</b>			
BZ	1999-05	650	ISO 46
DS	1999-05	650	ISO 46
<b>MAZDA RX8</b>			
	2003-->	430	ISO 46
<b>MAZDA TRIBUTE</b>			
	2001-05	850	ISO 46
<b>MAZDA XEDOS 6</b>			
	-->1999	700	ISO 46
<b>MAZDA XEDOS 9</b>			
	-->2001	750	ISO 46
<b>MERCEDES BENZ</b>			
<b>MERCEDES BENZ A</b>			
W168	1997-05	630	ISO 46
W169	2004-->	600	ISO 46
	2006-->	770	ISO 46
<b>MERCEDES BENZ B</b>			
W245		770	ISO 46
<b>MERCEDES BENZ B W245</b>			
B200CDI/TURBO		840	ISO 46
<b>MERCEDES BENZ C</b>			
W202	-->2001	900	ISO 46
<b>MERCEDES BENZ C W202</b>			
BZ	-->2001	950	ISO 46
BZ>VIN-1A168525		850	ISO 46
BZ>VIN-1F164270		850	ISO 46

DS	-->2001	900	ISO 46
	2000-->	750	ISO 46
<b>MERCEDES BENZ C W203</b>			
	-->04/04	750	ISO 46
	05/04-->	850	ISO 46
	2000-02	700	ISO 46
<b>MERCEDES BENZ CL W215</b>			
	1998-06	950	ISO 46
<b>MERCEDES BENZ CLK</b>			
W208	1997-02	850	ISO 46
W209	2002-06	750	ISO 46
<b>MERCEDES BENZ CLS W219</b>			
	2004-->	950	ISO 46
<b>MERCEDES BENZ E W124</b>			
-(2EV)	-->1996	1150	ISO 46
	-->1996	1000	ISO 46
<b>MERCEDES BENZ E W210</b>			
-(2EV)	1995-03	1150	ISO 46
	1995-03	1000	ISO 46
<b>MERCEDES BENZ E W211</b>			
	2002-->	950	ISO 46
<b>MERCEDES BENZ G W460-1-3</b>			
	1994-06	1000	ISO 46
<b>MERCEDES BENZ G300</b>			
	-->1995	1250	ISO 46
<b>MERCEDES BENZ GL</b>			
X164	2006-->	970	ISO 46
<b>MERCEDES BENZ M</b>			
	1998-02	750	ISO 46
	2005-06	970	ISO 46
<b>MERCEDES BENZ M W163</b>			
	1998-05	750	ISO 46
<b>MERCEDES BENZ M W164</b>			
	2005-->	970	ISO 46
<b>MERCEDES BENZ S W140</b>			
<VIN-1A128373< font>	(91-98)	1200	ISO 46
<VIN-1A128373< font>	(91-98)	1400	ISO 46
>VIN-1A128373	(91-98)	1150	ISO 46
>VIN-1A128373	(91-98)	1250	ISO 46
<b>MERCEDES BENZ S W220</b>			
	1998-05	1050	ISO 46
	1998-05	950	ISO 46
<b>MERCEDES BENZ SL</b>			
W230	2002-->	920	ISO 46
	-->2001	950	ISO 46
<b>MERCEDES BENZ SL W129</b>			
	-->2001	950	ISO 46
<b>MERCEDES BENZ SL W230</b>			

	2001-->	920	ISO 46
<b>MERCEDES BENZ SLK</b>			
W170	1996-02	850	ISO 46
	2004-06	670	ISO 46
<b>MERCEDES BENZ SLK W170</b>			
	1996-04	850	ISO 46
<b>MERCEDES BENZ SLK W171</b>			
	2004-->	670	ISO 46
<b>MERCEDES BENZ SPRINTER W901-4</b>			
-(2EV)	1999-06	1300	ISO 46
	1999-05	860	ISO 46
<b>MERCEDES BENZ SPRINTER W906</b>			
-(2EV)	2006-->	1125	ISO 46
	2006-->	740	ISO 46
<b>MERCEDES BENZ V W638</b>			
-(2EV)	1996-->	1100	ISO 46
-10PA17C	1996-->	920	ISO 46
-7SB16	1996-->	850	ISO 46
-SD7V16	1996-->	850	ISO 46
<b>MERCEDES BENZ VANEON W414</b>			
	2002-->	600	ISO 46
<b>MERCEDES BENZ VIANO W639</b>			
-(2EV)	2003-->	840	ISO 46
-(2EV-PL)	2003-->	870	ISO 46
	2003-->	550	ISO 46
<b>MERCEDES BENZ VITO</b>			
-COD-HZ7	2005-->	870	
	2005-->	550	
<b>MERCEDES BENZ VITO W638</b>			
-(2EV)	1995-03	1100	ISO 46
-10PA17C	1995-03	920	ISO 46
-7SB16	1995-03	850	ISO 46
-SD7V16	1995-03	850	ISO 46
<b>MERCEDES BENZ VITO W639</b>			
-(2EV)	2003-->	840	ISO 46
-(2EV-PL)	2003-->	870	ISO 46
	2003-->	550	ISO 46
<b>MERCEDES TRUK</b>			
<b>MERCEDES TRUK 667-670</b>			
A/C-FRONTALE		1225	ISO 46
<b>MERCEDES TRUK ACTROS</b>			
	1997-02	1300	
	2002-05	1100	
<b>MERCEDES TRUK ACTROS 930/2/3&gt;</b>			
C/AC-AUT.		1600	ISO 46
S/AC-AUT.		1100	ISO 46
<b>MERCEDES TRUK ACTROS 950A/954</b>			
CARR-972899		1000	ISO 46

**MERCEDES TRUK ATEGO 970/976**

CARR-972899		1000	ISO 46
-------------	--	------	--------

**MERCEDES TRUK AXOR**

	2000-04	1100	
--	---------	------	--

**MERCEDES TRUK AXOR 940/944**

CARR-944899		1100	ISO 46
-------------	--	------	--------

**MERCEDES TRUK AXOR 950/2/3/4**

CARR-940899		1200	ISO 46
-------------	--	------	--------

CARR-942899		1100	ISO 46
-------------	--	------	--------

**MERCEDES TRUK CANTER (MITSUB)**

10PA17C		920	ISO 46
---------	--	-----	--------

7SB16		850	ISO 46
-------	--	-----	--------

7SB16-A/C-AUT.		1100	ISO 46
----------------	--	------	--------

SD7V16		850	ISO 46
--------	--	-----	--------

**MERCEDES TRUK ECONIC**

957		800	ISO 46
-----	--	-----	--------

	2000-04	800	
--	---------	-----	--

**MERCEDES TRUK LKN 970/2/4/5/6**

CARR-972899		1000	ISO 46
-------------	--	------	--------

**MERCEDES TRUK T1/TN**

	1995-00	700	
--	---------	-----	--

	2000-04	860	
--	---------	-----	--

**MERCEDES TRUK UNIMOG**

	1996-00	1400	
--	---------	------	--

**MERCEDES TRUK VARIO**

	1996-->	1225	
--	---------	------	--

**MG****MG F (CAMBIO AT)**

	1995-02	700	ISO 100
--	---------	-----	---------

**MG F (CAMBIO MT)**

	1995-02	600	ISO 100
--	---------	-----	---------

**MG TF**

	2002-05	620	
--	---------	-----	--

**MG ZR**

	2001-05	640	ISO 46
--	---------	-----	--------

**MG ZS**

	2001-05	640	ISO 46
--	---------	-----	--------

**MG ZT**

	2001-05	450	ISO 46
--	---------	-----	--------

**MINI****MINI COOPER**

	2001-->	400	
--	---------	-----	--

**MINI ONE**

-CABRIO	2004-->	400	
---------	---------	-----	--

-DIESEL	2001-->	415	
---------	---------	-----	--

	2001-->	400	
--	---------	-----	--

**MITSUBISHI**

<b>MITSUBISHI 3000 GT</b>			
	-->2000	750	ISO 46
<b>MITSUBISHI CARISMA</b>			
	1995-03	700	ISO 46
<b>MITSUBISHI CHALLENGER</b>			
	1998-02	650	ISO 46
<b>MITSUBISHI COLT</b>			
	-->1996	590	ISO 46
	-->2004	600	ISO 46
	1988-92	1020	
	2004-->	430	ISO 46
<b>MITSUBISHI ECLIPSE</b>			
	1995-99	650	
<b>MITSUBISHI GALANT</b>			
	-->1997	670	ISO 46
	1988-92	1020	
	1997-02	710	ISO 46
<b>MITSUBISHI GRANDIS</b>			
-(2EV)	2004-->	750	ISO 46
	2004-->	560	ISO 46
	2005-->	750	ISO 46
<b>MITSUBISHI L200</b>			
	-->1997	740	ISO 46
	1997-06	575	ISO 46
	2006-->	555	ISO 46
<b>MITSUBISHI L300</b>			
-(2EV)	1994-->	1225	ISO 46
	1994-->	725	ISO 46
<b>MITSUBISHI L400</b>			
-(2EV)	1996-->	950	ISO 46
	1996-->	650	ISO 46
<b>MITSUBISHI LANCER</b>			
1.3	2005-->	520	
1.6	2005-->	520	
2	2005-->	520	
	-->2003	590	ISO 46
	2003-->	500	ISO 46
<b>MITSUBISHI LANCER BREAK</b>			
	-->1997	700	ISO 46
<b>MITSUBISHI MONTERO</b>			
-(2EV)	-->1994	1300	
-(2EV)	1994-00	1025	ISO 46
-(2EV)	1994-00	1050	ISO 46
-(2EV)	2000-->	750	ISO 46
-(2EV)	2000-02	800	ISO 46
-I.O.	2001-06	570	ISO 100
-SPORT	1998-02	650	ISO 46
	-->1994	850	

	1999-00	625	ISO 46
	2000-->	550	ISO 46
	2000-02	520	ISO 46
<b>MITSUBISHI OUTLANDER</b>			
	2004-->	570	ISO 46
<b>MITSUBISHI PAJERO</b>			
-(2EV)	1994-00	1025	ISO 46
-(2EV)	2000-->	750	ISO 46
-SPORT	1998-02	650	ISO 46
	-->1994	850	
	1999-00	640	ISO 100
	2000-02	520	ISO 46
<b>MITSUBISHI SIGMA</b>			
	1990-->	765	ISO 46
<b>MITSUBISHI SPACE GEAR</b>			
-(2EV)	-->1995	975	ISO 46
	-->1995	650	ISO 46
<b>MITSUBISHI SPACE RUNNER</b>			
	1994-98	720	ISO 46
	1999-->	550	ISO 46
<b>MITSUBISHI SPACE STAR</b>			
	1998-06	700	ISO 46
<b>MITSUBISHI SPACE WAGON</b>			
	-->1999	550	ISO 46
	1999-05	550	ISO 46
<b>NISSAN</b>			
<b>NISSAN 100 NZ</b>			
	-->1994	700	ISO 100
<b>NISSAN 200 SX (S14)</b>			
	1994-02	700	ISO 100
<b>NISSAN 300 ZX (Z32)</b>			
	-->1994	600	ISO 46
<b>NISSAN 350Z</b>			
	2003-->	550	ISO 46
<b>NISSAN 350ZX</b>			
	1994-96	600	ISO 46
<b>NISSAN ALMERA</b>			
-CALSONI	1995-00	650	ISO 46
-ZEXEL	1995-00	650	ISO 46
	2000-->	550	ISO 46
<b>NISSAN ALMERA TINO</b>			
	2000-02	550	ISO 46
<b>NISSAN CABSTAR</b>			
	-->1994	600	
	1986-95	650	ISO 46
	1994-00	700	ISO 46
	2004-->	750	ISO 46
<b>NISSAN INTERSTAR (X70)</b>			

-16-POST	2003-06	1400	ISO 150
-9-POSTI	2003-06	1300	ISO 150
	2003-06	850	ISO 150
<b>NISSAN KUBISTAR (X76)</b>			
	2003-07	660	ISO 46
<b>NISSAN MAXIMA</b>			
	1988-94	900	
	1994-02	700	ISO 46
<b>NISSAN MAXIMA (A33)</b>			
	2002-05	650	ISO 46
<b>NISSAN MICRA (K11)</b>			
	-->1994	560	ISO 100
	1994-00	450	ISO 100
	2000-02	500	ISO 46
<b>NISSAN MICRA (K12)</b>			
-MOT-K9K	02>	550	ISO 100
M-CR10/12/14	02>	475	ISO 100
<b>NISSAN MURANO (Z50)</b>			
	2005-->	525	ISO 46
<b>NISSAN NAVARA</b>			
	2005-->	750	
<b>NISSAN NAVARA (2EV)</b>			
	2005-->	900	
<b>NISSAN NAVARA (D22)</b>			
-Y25DDTi	2002-->	600	ISO 46
	1998-02	550	ISO 100
	2002-->	650	ISO 100
<b>NISSAN NAVARA (D40)</b>			
-(2EV)	2005-->	850	ISO 46
-MANUAL	2005-->	1080	ISO 46
	2005-->	700	ISO 46
<b>NISSAN NAVARA (MAN)</b>			
	2005-->	1130	
<b>NISSAN NOTE (E11)</b>			
-M-CR14/16	06-->	475	ISO 100
-M-K9K	06-->	550	ISO 100
<b>NISSAN PATHFINDER(R51)</b>			
-(2EV)	2004-->	850	ISO 46
	2004-->	700	ISO 46
<b>NISSAN PATROL</b>			
	1998-02	850	ISO 46
	2005-->	850	
<b>NISSAN PATROL (Y60)</b>			
-RD28T	92-98	1000	ISO 100
-TB42E	94-98	600	ISO 46
-TD42	92-98	1000	ISO 100
<b>NISSAN PATROL (Y61)</b>			
-RD28ETI	98-00	700	ISO 46

-ZD30DDTi	00-04	700	ISO 46
<b>NISSAN PATROL GR</b>			
	1994-98	650	ISO 46
<b>NISSAN PICK-UP</b>			
-K24E	1998-02	550	ISO 100
-KA24E	-->1998	800	ISO 100
-Z20/24	1988-94	800	ISO 46
<b>NISSAN PICK-UP (D22)</b>			
-K24DE	2002-->	650	ISO 100
<b>NISSAN PICK-UP DS(D21)</b>			
-SD23/SD25	85-87	850	ISO 100
-TD25	87-98	850	ISO 46
<b>NISSAN PICK-UP DS(D22)</b>			
-TD25/TI	1998-02	550	ISO 100
-Y25DDTi	2002-->	600	ISO 46
<b>NISSAN PICK-UP DS(D40)</b>			
-(2EV)	2005-->	850	ISO 46
-MANUAL	2005-->	1080	ISO 46
-Y25DDTi	2005-->	700	ISO 46
<b>NISSAN PRIMASTAR</b>			
	2002-06	700	ISO 150
<b>NISSAN PRIMERA (P/W10)</b>			
-ATSUGI	-->1997	750	ISO 46
-CALSONI	-->1997	600	ISO 46
-ZEXEL	-->1997	600	ISO 46
<b>NISSAN PRIMERA (P11)</b>			
-CD20T	1996-02	600	ISO 100
-GA16DE	1996-01	600	ISO 100
-QG16DE	2000-02	600	ISO 46
-QGA18DE	1996-02	600	ISO 46
-SR20DE	1996-02	600	ISO 100
TD	1999-02	650	ISO 100
<b>NISSAN PRIMERA (P12)</b>			
	2002-->	500	ISO 46
<b>NISSAN PRIMERA 4</b>			
	2002-->	500	
<b>NISSAN QX</b>			
-A32	1994-->	650	ISO 46
<b>NISSAN ROADSTAR</b>			
	2003-->	550	
<b>NISSAN SERENA (C23)</b>			
	7/96-->	625	ISO 46
	92-6/96	675	ISO 46
<b>NISSAN SERENA(C23-2EV)</b>			
	7/96-->	675	ISO 46
	92-6/96	725	ISO 46
<b>NISSAN SUNNY</b>			
-B13/N14	-->1998	750	ISO 46

-CABRIO	-->1995	600	ISO 100
-SW	-->1998	700	
<b>NISSAN SUNNY BREAK</b>			
	-->1994	800	ISO 100
	1994-96	750	ISO 100
<b>NISSAN TERRANO</b>			
-(R20)	-->2002	750	ISO 100
	-->2002	800	ISO 100
<b>NISSAN URVAN</b>			
-(2EV)	1994-96	1250	ISO 46
	1994-96	1000	ISO 46
<b>NISSAN VANETTE (C23H)</b>			
-(2EV)	7/96-02	675	ISO 46
-(2EV)	92-6/96	725	ISO 46
	7/96-02	525	ISO 46
	92-6/96	675	ISO 46
<b>NISSAN X-TRAIL</b>			
	2004-->	500	
<b>NISSAN X-TRAIL (T30)</b>			
-BZ	2001-->	500	ISO 46
-DS	2001-->	550	ISO 46
<b>OPEL</b>			
<b>OPEL AGILA</b>			
	2000-06	500	
<b>OPEL ANTARA</b>			
-Z20DMH	06-->	520	
-Z24XE-Z32SE	06>	660	
<b>OPEL ASTRA-F</b>			
(X17DTL)	1994-00	800	
	-->1994	700	ISO 150
	1994-98	650	ISO 150
<b>OPEL ASTRA-G</b>			
2-T.	1998-02	700	ISO 46
TDIESEL	1998-02	600	ISO 46
	1998-02	700	ISO 46
	2002-06	600	ISO 46
<b>OPEL ASTRA-H</b>			
-1,4,6,8	2004>	475	ISO 46
-DS	2004-->	475	ISO 46
2,0-T.TOP	2004->	625	ISO 46
2,0/2,0T	2004-->	500	ISO 46
TWIN-TOP	2004-->	625	ISO 46
	2004-06	500	ISO 46
<b>OPEL CALIBRA</b>			
-NEW-TXV	1994-->	1000	ISO 150
-OLD-TXV	1994-->	750	ISO 150
<b>OPEL COMBO</b>			
	2002-06	550	

<b>OPEL COMBO-B</b>			
	-->2001	900	ISO 46
<b>OPEL COMBO-C</b>			
(ALL-BZ)	2001-07	650	ISO 100
-1.3-CDT	2001-07	560	ISO 100
-1.7-CDT	2001-07	560	ISO 100
-1.7-DTi	2001-05	560	ISO 100
-1.7-Di	2001-03	650	ISO 100
-1.7-Di	2004-->	560	ISO 100
	2004-06	560	
<b>OPEL CORSA-B</b>			
	-->2001	900	ISO 46
<b>OPEL CORSA-C</b>			
(ALL-BZ)	2000-07	650	ISO 100
-Di/DTi	2000-06	550	
<b>OPEL CORSA-D</b>			
-Z10/Z12	07-->	430	
-Z14XEP	07-->	430	
-Z16LER	07-->	470	
-Z17DTR	07-->	520	
Z13DTH/DTJ	07-->	520	
<b>OPEL FRONTERA-A</b>			
BZ	1991-2/95	800	
BZ	3/95-8/96	750	
BZ	9/96-98	650	
DS	-->1998	700	
<b>OPEL FRONTERA-B</b>			
-Y22DTH	2002-04	700	ISO 100
BZ	1998-02	650	
DS	1998-04	650	
<b>OPEL MERIVA</b>			
BZ	2003-->	690	ISO 46
DS	2003-05	690	ISO 46
DS	2005-->	650	ISO 46
<b>OPEL MONTEREY</b>			
D	1994-98	750	ISO 46
	1994-98	750	ISO 100
<b>OPEL MOVANO</b>			
-1,9DTi	1999-03	850	ISO 100
-2,5DTi	1998-01	850	ISO 100
-2,8TD	1998-03	850	ISO 100
-DELPHI	03-->	850	ISO 150
-SANDEN	03-->	850	ISO 46
16POS-DELP	03-->	1400	ISO 150
16POS-SAND	03-->	1400	ISO 46
9POS-DELPH	03-->	1300	ISO 150
9POS-SANDE	03-->	1300	ISO 46
	1998-02	900	ISO 100

<b>OPEL OMEGA-A</b>			
	1986-94	1100	
<b>OPEL OMEGA-B</b>			
-X20SE	1994-96	950	ISO 150
-X20XEV	1994-00	950	ISO 150
-X25DT	1994-01	950	ISO 46
-X25XE	1994-00	950	ISO 150
-X30XE	1994-00	950	ISO 150
-Y25DT	1994-01	950	ISO 46
<b>OPEL SENATOR</b>			
	1988-93	1100	
<b>OPEL SIGNUM</b>			
-Y30DT	2003-06	680	ISO 46
-Z28NEL	2006-->	660	ISO 46
-Z30DT	2006-->	660	ISO 46
	2003-->	730	ISO 46
<b>OPEL SINTRA</b>			
	1996-99	910	ISO 150
<b>OPEL TIGRA</b>			
Y17	2004-->	560	ISO 46
Z10	2004-->	650	ISO 46
Z12	2004-->	650	ISO 46
Z13	2004-->	560	ISO 46
Z14	2004-->	650	ISO 46
Z16	2004-->	650	ISO 46
	1995-00	900	ISO 46
<b>OPEL TIGRA-B</b>			
-Z13DT	2004-->	560	ISO 100
-Z14XEP	2004-->	650	ISO 100
-Z18XE	2004-->	650	ISO 100
<b>OPEL VECTRA-A</b>			
	-->1994	750	ISO 150
	1994-95	1000	ISO 150
<b>OPEL VECTRA-B</b>			
-1,6i/16	1995-02	900	ISO 150
-1.8-16V	1995-02	900	ISO 150
-2,0i	1995-01	900	ISO 150
-X17DT	1995-96	900	ISO 46
-X20DTH	1997-00	750	ISO 150
-X20DTL	1997-00	750	ISO 150
-X22SE	2000-02	900	ISO 150
-X25XE	1995-00	900	ISO 46
-Y20DTH	2000-02	750	ISO 150
-Y22DTR	2000-02	750	ISO 150
-Y26SE	2000-02	900	ISO 46
<b>OPEL VECTRA-C</b>			
-Y30DT	2003-06	680	ISO 46
-Z28NEL	2006-->	660	ISO 46

-Z28NET	2006-->	660	ISO 46
-Z30DT	2006-->	660	ISO 46
	2002-->	730	ISO 46

### OPEL VIVARO

-2EV	2001-->	1050	ISO 150
	2001-06	750	ISO 150
	2002-06	750	ISO 150

### OPEL ZAFIRA-A

-2EV	2000-01	950	ISO 46
-2EV	2002-05	800	ISO 46
	2000-01	700	ISO 46
	2002-05	600	ISO 46

### OPEL ZAFIRA-B

	2005-06	475	ISO 46
	2006-->	450	ISO 46

### PEUGEOT

#### PEUGEOT 1007

	2005-->	625	ISO 46
--	---------	-----	--------

#### PEUGEOT 106

-TU1-SDH13	91-97	875	ISO 100
-TU1-SDH15	91-97	875	ISO 100
-TU1-SDV12	91-97	875	ISO 46
-TU1-SDV16	91-97	875	ISO 46
-TU1M	1997-03	825	ISO 46
-TU2J2L/Z	94-97	875	ISO 46
-TU3-SDH13	91-96	875	ISO 100
-TU3-SDH15	91-96	875	ISO 100
-TU3-SDV12	91-96	875	ISO 46
-TU3-SDV16	91-96	875	ISO 46
-TU3JP	1997-03	825	ISO 46
-TU5D	1997-03	750	ISO 46
-TU5J	1997-03	825	ISO 46
-TU5J2	1994-96	875	ISO 46
-TU5J4	1997-03	750	ISO 46
-TU9M	1996-97	875	ISO 46
-TU9M	1997-03	825	ISO 46
-TU9MZ	-->1996	875	ISO 46
-TUD3-SD	92-95	875	ISO 100
-TUD3-SD	92-95	875	ISO 46
-TUD3-SD7	92-95	875	ISO 46
-TUD5	1994-97	875	ISO 46
S1-SD6V12/7V12		875	ISO 46
S2-SD6V12		890	ISO 46
S2-SD7V12		915	ISO 46

#### PEUGEOT 107

-DV4TD	2005-->	500	ISO 100
384F(CFA)	2005-->	450	ISO 100

#### PEUGEOT 205

	-->1998	650	ISO 100
<b>PEUGEOT 206 (9HZ)</b>			
-DV6TED4	04-07	630	ISO 46
<b>PEUGEOT 206 (RFK)</b>			
-EW10J4S	02-02	675	ISO 46
<b>PEUGEOT 206 (RFN)</b>			
-EW10J4	00-06	675	ISO 46
<b>PEUGEOT 206 (RFR)</b>			
-EW10J4	99-00	675	ISO 46
<b>PEUGEOT 206 (RHY)</b>			
-DW10TD	99-07	675	ISO 46
<b>PEUGEOT 207</b>			
	2006-->	450	ISO 46
<b>PEUGEOT 305</b>			
SD508		800	
<b>PEUGEOT 306</b>			
	-->1997	900	ISO 46
	1997-03	725	ISO 46
<b>PEUGEOT 307</b>			
>N.DAM-10080<<		560	ISO 46
>N.DAM-10081>>		425	ISO 46
>N.DAM-10218<<		560	ISO 46
>N.DAM-10219>>		425	ISO 46
<b>PEUGEOT 307 (8HZ)</b>			
->10080-DV4TD		585	ISO 46
10081->-DV4TD		450	ISO 46
<b>PEUGEOT 307 (9HY)</b>			
->10218-DV6TED4		585	ISO 46
->10218DV6ATED4		585	ISO 46
10219-->-DV6TED4		450	ISO 46
10219->DV6ATED4		450	ISO 46
<b>PEUGEOT 307 (9HZ)</b>			
->10218-DV6TED4		585	ISO 46
10219->-DV6TED4		450	ISO 46
<b>PEUGEOT 307 (KFU)</b>			
->10080-ET3J4		585	ISO 46
10081->-ET3J4		450	ISO 46
<b>PEUGEOT 307 (KFW)</b>			
-TU3JP	01-05	585	ISO 46
<b>PEUGEOT 307 (N6A)</b>			
->10080-TU5JP4		585	ISO 46
10081->-TU5JP4		450	ISO 46
<b>PEUGEOT 307 (NFU)</b>			
->10080-TU5JP4		585	ISO 46
10081->-TU5JP4		450	ISO 46
<b>PEUGEOT 307 (RFJ)</b>			
->10080-EW10A		585	ISO 46
10081->-EW10A		450	ISO 46

<b>PEUGEOT 307 (RFK)</b>			
->10080-EW10J4S		585	ISO 46
10081-->EW10J4S		450	ISO 46
<b>PEUGEOT 307 (RFN)</b>			
->10080-EW10J4		585	ISO 46
10081-->EW10J4		450	ISO 46
<b>PEUGEOT 307 (RHR)</b>			
10081>DW10BTED4		450	ISO 46
>10080DW10BTED4		585	ISO 46
<b>PEUGEOT 307 (RHS)</b>			
->10080DW10ATED		585	ISO 46
10081->DW10ATED		450	ISO 46
<b>PEUGEOT 307 (RHY)</b>			
->10080-DW10TD		585	ISO 46
10081-->DW10TD		450	ISO 46
<b>PEUGEOT 307 (RHZ)</b>			
->10080DW10ATED		585	ISO 46
10081->DW10ATED		450	ISO 46
<b>PEUGEOT 307 RESTYLING</b>			
	06.05-06	425	ISO 46
<b>PEUGEOT 309</b>			
	1986-93	900	
<b>PEUGEOT 405</b>			
-SD7H15	1994-97	675	ISO 100
<b>PEUGEOT 406</b>			
-DELPHI	1995-99	750	ISO 46
-DW10	98-04	625	ISO 150
-DW12ATED	98-04	625	ISO 150
-ES9J4	1997-04	750	ISO 46
-EW10D	00-04	625	ISO 46
-EW10J4	1999-04	600	ISO 46
-EW12J4	1999-04	600	ISO 46
-EW7J4	2002-04	600	ISO 46
-SANDEN	1995-99	800	ISO 150
-XU	1999-01	775	ISO 46
-XUD11	95-00	800	ISO 46
-XUD11DELP	95-00	750	ISO 150
-XUD9	95-00	800	ISO 46
-XUD9-DELP	95-00	750	ISO 150
<b>PEUGEOT 406 COUPE"</b>			
AB-MJ01-SD7V16		750	ISO 46
BIS-MJ01-SD7V16		775	ISO 46
<b>PEUGEOT 406 D8</b>			
ES-SD7V16		750	ISO 46
XU/XUD-SD7V16		800	ISO 150
XUD7448-HV5		750	ISO 150
<b>PEUGEOT 406 D9</b>			
DELPHI-V5		625	ISO 150

EW/DW-SD7V16		625	ISO 46
XU/ES9-SD7V16		775	ISO 46
<b>PEUGEOT 407</b>			
DE17TED4	2006-->	525	ISO 46
DW12BTED4	2006-->	525	ISO 46
	2004-->	625	ISO 46
<b>PEUGEOT 605</b>			
-SD7H13	-->2000	885	ISO 100
-SD7H15	-->2000	885	ISO 100
-SD7V12	-->2000	885	ISO 46
-SD7V16	-->2000	885	ISO 46
-mot-ES9J4	97-00	850	ISO 46
mot-DK5ATE	95-00	850	ISO 46
<b>PEUGEOT 607</b>			
	2000-->	625	ISO 46
<b>PEUGEOT 607 (4HT)</b>			
-DW12BTED4	05-->	550	ISO 46
<b>PEUGEOT 607 (RHR)</b>			
-DW10BTED4	05-->	550	ISO 46
<b>PEUGEOT 607 (UHZ)</b>			
-DT17TED4	04-->	600	ISO 46
<b>PEUGEOT 607 (XFV)</b>			
-ES9A	04-->	550	ISO 46
<b>PEUGEOT 806 (RFR)</b>			
-EW10J4	00-01	975	ISO 46
-EW10J4	01-02	950	ISO 46
<b>PEUGEOT 806 (RFV)</b>			
-XU10J4R	00-01	975	ISO 46
-XU10J4R	01-02	950	ISO 46
<b>PEUGEOT 806 (RHW)</b>			
-DW10ATED4	01-02	950	ISO 46
<b>PEUGEOT 806 (RHZ)</b>			
-DW10ATED	01-02	950	ISO 46
-DW10ATED	09-01	975	ISO 46
<b>PEUGEOT 807</b>			
SD7V16		600	ISO 46
<b>PEUGEOT BOXER 1</b>			
-->VIN-15324952		1000	ISO 100
VIN-15324952-->		800	ISO 100
<b>PEUGEOT BOXER 1 (2EV)</b>			
-->VIN-15324952		1200	ISO 100
VIN-15324952-->		1000	ISO 100
<b>PEUGEOT BOXER 2</b>			
-(2EV)	2002-06	700	ISO 100
	2002-06	500	ISO 100
<b>PEUGEOT EXPERT</b>			
	1995-01	975	ISO 46
	2001-->	950	ISO 46

	2004-->	1000	ISO 46
<b>PEUGEOT PARTNER</b>			
BZ	-->9/2002	875	ISO 46
BZ	10/2002-->	575	ISO 46
DS	-->9/2002	725	ISO 46
DS	10/2002-->	575	ISO 46
<b>PEUGEOT RANCH</b>			
BZ	-->9/2002	875	ISO 46
BZ	10/2002-->	575	ISO 46
DS	-->9/2002	725	ISO 46
DS	10/2002-->	575	ISO 46
<b>PORSCHE</b>			
<b>PORSCHE 911</b>			
	-->1997	840	ISO 46
	1997-->	900	ISO 46
<b>PORSCHE 928</b>			
	-->2005	1150	
<b>PORSCHE 968</b>			
	-->2005	860	
<b>PORSCHE BOXSTER</b>			
	1997-04	850	ISO 46
	2004-->	875	ISO 46
<b>PORSCHE CAYENNE</b>			
(2EV)	2005-->	1100	ISO 46
	2005-->	650	ISO 46
<b>PROTON</b>			
<b>PROTON IMPIAN</b>			
-mot.4G18P	2001>	575	ISO 46
<b>PROTON WAJA</b>			
-mot.4G18P	2001>	575	ISO 46
<b>RENAULT</b>			
<b>RENAULT 19</b>			
-Cil.Fissa	->96	800	ISO 100
-Cil.Var.	->96	800	ISO 46
<b>RENAULT 21</b>			
	-->1995	750	ISO 100
<b>RENAULT AVANTIME DELPHI</b>			
-F4R-760	00-03	800	ISO 150
-G9T-718	00-03	850	ISO 150
-L7X-721/2	00-03	880	ISO 150
<b>RENAULT AVANTIME SANDEN</b>			
-F4R-760	00-03	800	ISO 46
-G9T-718	00-03	850	ISO 46
-L7X-721/2	00-03	880	ISO 46
<b>RENAULT CLIO</b>			
	-->1998	660	ISO 100
	1998-06	650	ISO 46
	2001-05	680	ISO 46

	2005-->	560	ISO 46
<b>RENAULT ESPACE</b>			
	-->1994	1500	
<b>RENAULT ESPACE 2 (J63)</b>			
	-->1997	1250	ISO 100
<b>RENAULT ESPACE 3 (JEO)</b>			
-F3R	1996-99	820	ISO 100
-F4R	1998-02	750	ISO 100
-F9Q	1999-02	720	ISO 46
-G8T	1997-00	800	ISO 100
-G9T	2000-02	700	ISO 100
-L7X	1998-02	890	ISO 46
-Z7X	1996-99	820	ISO 100
<b>RENAULT ESPACE 4 (JKO)</b>			
-ALL	2002-->	1000	ISO 150
-P9X	2002-06	650	ISO 150
-V4Y	2002-06	650	ISO 150
<b>RENAULT EXPRESS</b>			
	-->1994	850	
	-->1995	680	ISO 100
	1994-01	715	ISO 46
	1995-02	675	ISO 46
<b>RENAULT EXTRA</b>			
	1986-95	680	ISO 100
	1995-02	675	ISO 46
<b>RENAULT GRAND SCENIC II</b>			
	2004-->	550	ISO 46
<b>RENAULT KANGOO</b>			
-F8Q	1998-04	680	ISO 46
-F9Q-780/2	99-03	700	ISO 46
	1998-07	660	ISO 46
<b>RENAULT LAGUNA 1 (X56)</b>			
-F3P	1994-98	700	ISO 46
-F3R	1994-01	700	ISO 46
-F4P	1998-01	700	ISO 46
-F4R	1999-01	700	ISO 46
-G8T	1994-96	800	ISO 100
-G8T-752	96-98	780	ISO 100
-G8T-760	96-99	780	ISO 46
-K4M	1998-01	700	ISO 46
-L7X	1997-01	780	ISO 46
-N7Q	1999-01	700	ISO 100
-Z7X	1994-98	780	ISO 46
F9Q-710/	1999-01	700	ISO 46
F9Q718/754	19-01	700	ISO 46
<b>RENAULT LAGUNA 2</b>			
-ALL	2001-05	650	ISO 150
-L7X-731	2001-05	650	ISO 46

**RENAULT LAGUNA 3**

-ALL	2005-->	650	ISO 150
-L7X-733	2005-->	650	ISO 46

**RENAULT MASCOTT**

-S9W	1999-->	850	
-ZD3	1999-->	750	

**RENAULT MASTER 2**

-DELPHI	1998-03	850	ISO 150
-DELPHI-9P	98-03	1300	ISO 150
-SANDEN	1998-03	850	ISO 46
-SANDEN	98-03	1400	ISO 46
-SANDEN-9P	98-03	1300	ISO 46
DELPHI-16P	98-03	1400	ISO 150

**RENAULT MASTER 3**

-DELPHI	2003-->	850	ISO 150
-DELPHI-9P	2003-->	1400	ISO 150
-SANDEN	2003-->	850	ISO 46
-SANDEN-9P	2003-->	1400	ISO 46
DELPHI-16P	2003-->	1200	ISO 150
SANDEN-16P	2003-->	1200	ISO 46

**RENAULT MEGANE 1**

-E7J	1995-99	750	ISO 150
-F3R	1995-99	780	ISO 46
-F7R-DELPHI	>99	750	ISO 150
-F7R-SANDEN	>99	750	ISO 46
-F8Q-620/624	>99	750	ISO 150
-F8Q-784/786	>99	750	ISO 150
-F9Q	1997-99	750	ISO 150
-K7M-DELPH	95-99	750	ISO 150
-K7M-SANDE	95-99	750	ISO 46

**RENAULT MEGANE 2**

-E7J	1999-03	750	ISO 150
-F4P	2000-03	750	ISO 150
-F4R	1999-03	750	ISO 150
-F5R	1999-03	750	ISO 150
-F8Q	1999-03	750	ISO 150
-F9Q	1999-03	750	ISO 150
-K4J	1999-03	700	ISO 150
-K4M	1999-03	700	ISO 150

**RENAULT MEGANE 3**

-F4R	2002-->	550	ISO 150
-F9Q	2002-->	550	ISO 150
-K4J	2002-->	550	ISO 150
-K4M	2002-->	550	ISO 150
-K9K	2003-->	550	ISO 150

**RENAULT MEGANE SCENIC**

	1996-99	835	ISO 46
--	---------	-----	--------

**RENAULT MODUS**

	2004-->	510	ISO 46
<b>RENAULT RAPID</b>			
	1986-->	700	ISO 46
<b>RENAULT SAFRANE</b>			
-J7R	-->1997	850	ISO 46
-J7R-732/733	>97	850	ISO 46
-J7R-734/735	>97	850	ISO 46
-J8S-cil.fiS	>00	850	ISO 100
-J8S-cil.var	>00	850	ISO 46
-N7Q	1996-01	780	ISO 46
2	1996-01	810	ISO 46
2,2TD	1996-01	810	ISO 46
2.5	1996-01	810	ISO 46
<b>RENAULT SCENIC</b>			
	1999-02	715	ISO 150
	2003-->	550	ISO 46
<b>RENAULT TRAFFIC</b>			
-(2EV)	2001-06	1050	ISO 150
-(2EV)	2007-->	1150	ISO 46
	2001-->	725	ISO 46
	2001-06	750	ISO 150
	2007-->	725	ISO 46
<b>RENAULT TWINGO</b>			
-C3G	-->1997	650	ISO 46
-D4F	1996-07	700	ISO 46
-D7F	1996-07	740	ISO 46
<b>RENAULT VEL SATIS</b>			
	2002-->	650	ISO 150
<b>RENAULT TRUK</b>			
<b>RENAULT TRUK KERAX</b>			
	1997-99	1400	
<b>RENAULT TRUK MAGNUM</b>			
	2000-06	1450	
<b>RENAULT TRUK MASCOTT</b>			
	2000-06	900	
<b>RENAULT TRUK MASTER</b>			
	1998-->	850	
<b>RENAULT TRUK MIDLINER</b>			
	1996-99	1200	
<b>RENAULT TRUK MIDLUM</b>			
	2000-->	1200	ISO 100
<b>RENAULT TRUK PREMIUM</b>			
	1996-99	1400	
<b>ROVER</b>			
<b>ROVER 200</b>			
-<TEL.605482< font>	>00	650	ISO 46
->tel.605482	>00	700	ISO 46
<b>ROVER 25</b>			

	1999-04	640	ISO 46
<b>ROVER 400</b>			
-<TEL.605482< font>	>00	650	ISO 46
->tel.605482	>00	700	ISO 46
<b>ROVER 45</b>			
	1999-05	650	ISO 46
<b>ROVER 600</b>			
	-->1999	750	ISO 46
<b>ROVER 75</b>			
	1999-05	450	ISO 46
<b>ROVER 825</b>			
->tel.152206	>99	650	ISO 46
2,5TD	-->1994	1020	
2,5TD	1994-99	700	ISO 46
<b>ROVER 827</b>			
	1994-->	650	ISO 46
<b>ROVER CDV</b>			
	2003-05	640	ISO 46
<b>ROVER CITYROVER</b>			
	2005-->	660	ISO 46
<b>ROVER MG EXPRESS</b>			
	2005-05	640	ISO 46
<b>ROVER MG ZR</b>			
	1999-02	665	ISO 46
	2002-05	640	ISO 46
<b>ROVER MG ZS</b>			
	1999-02	690	ISO 46
	2002-05	640	ISO 46
<b>ROVER MG ZT</b>			
	1999-02	500	ISO 46
	2002-05	450	ISO 46
<b>ROVER MGF</b>			
-auto	1995-02	730	ISO 100
-camb.AT	1995-02	700	ISO 100
	1995-02	630	ISO 100
<b>ROVER MGR V8</b>			
	-->1996	700	
<b>ROVER STREETWISE</b>			
	2003-05	640	ISO 46
<b>ROVER ZT-T</b>			
	1999-02	500	ISO 46
	2002-05	450	ISO 46
<b>SAAB</b>			
<b>SAAB 9-3</b>			
-diesel	1998-02	800	ISO 100
	1998-03	800	ISO 46
	2002-06	680	ISO 46
<b>SAAB 9-5</b>			

-ALL	1998-04	875	ISO 46
-ALL	2005-->	825	ISO 46
-diesel	2002-06	850	ISO 46
	1997-06	850	ISO 46

### **SAAB 900**

-B204I	1995-97	725	ISO 100
-B204I	1997-98	725	ISO 46
-B204L	1995-97	725	ISO 100
-B204L	1997-98	725	ISO 46
-B206I	1994	725	ISO 46
-B234I	1995-97	725	ISO 100
-B234I	1997-98	725	ISO 46
-B258I	1995-97	725	ISO 100
-B258I	1997-98	725	ISO 46

### **SAAB 9000**

	-->1998	950	ISO 100
--	---------	-----	---------

### **SCANIA**

#### **SCANIA 113**

	-->1996	800	
--	---------	-----	--

#### **SCANIA 114/124**

	1996-98	1450	
--	---------	------	--

#### **SCANIA 143**

	-->1996	800	
--	---------	-----	--

#### **SCANIA 144**

	1995-->	1450	
--	---------	------	--

#### **SCANIA 164**

	2000-->	1450	
--	---------	------	--

#### **SCANIA 93**

	1988-96	800	
--	---------	-----	--

#### **SCANIA 94**

	1996-->	1450	
--	---------	------	--

#### **SCANIA R**

	2004-->	1250	
--	---------	------	--

#### **SCANIA T113**

	-->1996	800	
--	---------	-----	--

#### **SCANIA T114**

	1998-->	1450	
--	---------	------	--

#### **SCANIA T124**

	1996-->	1450	
--	---------	------	--

#### **SCANIA T143**

	-->1996	800	
--	---------	-----	--

#### **SCANIA T144**

	1995-->	1450	
--	---------	------	--

#### **SCANIA T93**

	1996-->	800	
--	---------	-----	--

#### **SCANIA T94**

	1996-->	1450	
--	---------	------	--

### **SEAT**

<b>SEAT ALHAMBRA 1</b>			
-(2EV)	1996-5/00	1375	ISO 46
-(2EV)	6/00-->	1075	ISO 46
	1996-5/00	975	ISO 46
	6/00-->	725	ISO 46
<b>SEAT ALHAMBRA 2</b>			
-(2EV)	2000-->	1075	ISO 46
	2000-->	725	ISO 46
<b>SEAT ALTEA</b>			
-AXW	2004-05	525	ISO 46
-AZV	2004-->	525	ISO 46
-BGU	2004-05	525	ISO 46
-BJB	2004-->	525	ISO 46
-BKC	2004-->	525	ISO 46
-BKD	2004-->	525	ISO 46
-BLR	2004-->	525	ISO 46
-BLS	2006-->	525	ISO 46
-BLY	2004-->	525	ISO 46
-BMM	2006-->	525	ISO 46
-BSE	2005-->	525	ISO 46
-BSF	2005-->	525	ISO 46
<b>SEAT AROSA</b>			
	1997-05	725	ISO 100
<b>SEAT CORDOBA</b>			
	-->1999	880	ISO 46
	1999-02	800	ISO 46
	2002-06	550	ISO 46
<b>SEAT IBIZA</b>			
	-->1999	880	ISO 46
	1999-02	800	ISO 46
<b>SEAT IBIZA 3</b>			
-AEK	1999-02	775	ISO 46
-AFR	2000-02	775	ISO 46
-AGP	1999-02	775	ISO 46
-AGR	1999-02	775	ISO 46
-AKK	1999-02	775	ISO 46
-AKL	1999-02	775	ISO 46
-ALD	1999-02	775	ISO 46
-ALH	1999-02	775	ISO 46
-ALM	1999-02	775	ISO 46
-ANV	1999-02	775	ISO 46
-ANW	1999-02	775	ISO 46
-APE	1999-02	775	ISO 46
-APP	1999-00	775	ISO 46
-AQM	1999-02	775	ISO 46
-AQQ	1999-02	775	ISO 46
-AQX	1999-02	775	ISO 46
-ASV-CUPRA	-->02	775	ISO 46

-AUA	2000-02	775	ISO 46
-AUB	2001-02	775	ISO 46
-AUC	2000-02	775	ISO 46
-AUD	1999-02	775	ISO 46
-AUR	1999-02	775	ISO 46
-AVZ	2000-02	775	ISO 46
-AYP	2000-02	775	ISO 46

#### SEAT IBIZA 4

-AMF	2003-->	550	ISO 46
-ASY	2002-->	550	ISO 46
-ASZ	2002-->	550	ISO 46
-ATD	2002-->	550	ISO 46
-AUB	2002-03	550	ISO 46
-AZL	2003-05	550	ISO 46
-AZQ	2002-05	550	ISO 46
-BBU	2004-->	550	ISO 46
-BBX	2003-->	550	ISO 46
-BBY	2002-04	550	ISO 46
-BBZ	2002-->	550	ISO 46
-BJX	2005-->	550	ISO 46
-BKV	2005-->	550	ISO 46
-BLZ	2005-->	550	ISO 46

#### SEAT INCA

-(2EV)	2002-->	930	ISO 46
	1995-02	880	ISO 46
	2002-->	870	ISO 46

#### SEAT LEON

	1999-05	800	ISO 46
--	---------	-----	--------

#### SEAT LEON 1

-AEH	1999-05	775	ISO 46
-AGN	1999-05	775	ISO 46
-AGP	2000-05	775	ISO 46
-AGR	1999-05	775	ISO 46
-AHF	1999-05	775	ISO 46
-AHW	1999-05	775	ISO 46
-AJQ	1999-00	775	ISO 46
-AKL	1999-05	775	ISO 46
-ALH	1999-05	775	ISO 46
-AMK	2002-05	775	ISO 46
-APE	2000-05	775	ISO 46
-APG	2001-05	775	ISO 46
-APP	1999-05	775	ISO 46
-APT	2001-05	775	ISO 46
-AQM	2000-05	775	ISO 46
-ARL	2000-05	775	ISO 46
-ARY	2001-05	775	ISO 46
-ASV	2000-05	775	ISO 46
-AUE	2001-05	775	ISO 46
-AUQ	2001-05	775	ISO 46

-AUS	2000-05	775	ISO 46
-AXP	2000-05	775	ISO 46
-AZD	2001-05	775	ISO 46
-BAM	2003-05	775	ISO 46
-BCA	2000-05	775	ISO 46
-BCD	2001-05	775	ISO 46
-BDE	2001-05	775	ISO 46
-BFQ	2002-04	775	ISO 46

### SEAT LEON 2

-AZV	2005-->	525	ISO 46
-BGU	2005-->	525	ISO 46
-BJB	2005-->	525	ISO 46
-BKC	2005-->	525	ISO 46
-BKD	2005-->	525	ISO 46
-BLR	2005-->	525	ISO 46
-BLS	2005-->	525	ISO 46
-BLY	2005-->	525	ISO 46
-BMM	2005-->	525	ISO 46
-BSE	2005-->	525	ISO 46
-BVY	2005-->	525	ISO 46
-BWA	2005-->	525	ISO 46
-BWA1	2005-->	525	ISO 46
-BXE	2005-->	525	ISO 46
-BXW	2005-->	525	ISO 46

### SEAT TOLEDO

	-->1999	880	ISO 46
	1999-05	800	ISO 46

### SEAT TOLEDO 3

-AZV	2005-->	525	ISO 46
-BGU	2005-->	525	ISO 46
-BJB	2005-->	525	ISO 46
-BKC	2005-->	525	ISO 46
-BKD	2005-->	525	ISO 46
-BLR	2005-->	525	ISO 46
-BLS	2005-->	525	ISO 46
-BLY	2005-->	525	ISO 46
-BMM	2005-->	525	ISO 46
-BSE	2005-->	525	ISO 46
-BSF	2005-->	525	ISO 46
-BVY	2005-->	525	ISO 46
-BVZ	2005-->	525	ISO 46
-BXW	2004-->	525	ISO 46

### SKODA

#### SKODA FABIA 1

-AME	1999-03	550	ISO 46
-AMF	2003-06	550	ISO 46
-AQV	2001-03	550	ISO 46
-AQW	2000-03	550	ISO 46

-ARV	2001-03	550	ISO 46
-ASY	1999-07	550	ISO 46
-ASZ	2003-06	550	ISO 46
-ATD	2000-05	550	ISO 46
-ATY	1999-03	550	ISO 46
-ATZ	1999-00	550	ISO 46
-AUA	2000-02	550	ISO 46
-AUB	1999-02	550	ISO 46
-AWY	2002-04	550	ISO 46
-AXR	2005-07	550	ISO 46
-AZE	2000-03	550	ISO 46
-AZF	2000-03	550	ISO 46
-AZL	2000-07	550	ISO 46
-AZQ	2003-05	550	ISO 46
-BBY	2002-04	550	ISO 46
-BBZ	2000-07	550	ISO 46
-BKY	2004-07	550	ISO 46
-BLT	2005-07	550	ISO 46
-BMD	2004-07	550	ISO 46
-BME	2004-07	550	ISO 46
-BNM	2005-07	550	ISO 46
-BNV	2005-07	550	ISO 46
-BUD	2006-07	550	ISO 46

### SKODA FABIA 2

-BBM	2007-->	550	ISO 46
-BLS	2007-->	550	ISO 46
-BMS	2007-->	550	ISO 46
-BNM	2007-->	550	ISO 46
-BNV	2007-->	550	ISO 46
-BSW	2007-->	550	ISO 46
-BTS	2007-->	550	ISO 46
-BXW	2007-->	550	ISO 46
-BZG	2007-->	550	ISO 46

### SKODA FELICIA

-mot.-135	94-01	765	ISO 100
-mot.-135M	94-01	765	ISO 100
-mot.-136M	94-01	765	ISO 100
-mot.-AEE	95-01	735	ISO 46

### SKODA OCTAVIA 1

-AEE	1996-04	775	ISO 46
-AEG	2001-04	775	ISO 46
-AEH	1997-04	775	ISO 46
-AGN	1996-99	775	ISO 46
-AGP	1997-01	775	ISO 46
-AGR	1996-04	775	ISO 46
-AGU	1998-04	775	ISO 46
-AHF	1997-04	775	ISO 46
-AKL	1997-04	775	ISO 46
-ALH	2000-04	775	ISO 46

-AMD	1999-01	775	ISO 46
-APK	2000-04	775	ISO 46
-AQM	2000-04	775	ISO 46
-AQY	1999-02	775	ISO 46
-ARX	2000-04	775	ISO 46
-ARZ	1999-00	775	ISO 46
-ASV	1999-04	775	ISO 46
-ASZ	2002-04	775	ISO 46
-ATD	2000-04	775	ISO 46
-AUM	2000-04	775	ISO 46
-AUQ	2000-04	775	ISO 46
-AVU	2000-02	775	ISO 46
-AXP	2000-02	775	ISO 46
-AZH	2000-02	775	ISO 46
-AZJ	2001-04	775	ISO 46
-BCA	2002-04	775	ISO 46
-BFQ	2002-04	775	ISO 46

### SKODA OCTAVIA 2

-AZV	2004-->	550	ISO 46
-BCA	2004-07	550	ISO 46
-BGU	2004-06	550	ISO 46
-BJB	2004-->	550	ISO 46
-BKC	2004-07	550	ISO 46
-BKD	2004-->	550	ISO 46
-BLF	2004-->	550	ISO 46
-BLR	2004-06	550	ISO 46
-BLS	2006-->	550	ISO 46
-BLX	2004-06	550	ISO 46
-BLY	2004-06	550	ISO 46
-BMM	2005-->	550	ISO 46
-BMN	2006-->	550	ISO 46
-BSE	2005-->	550	ISO 46
-BSF	2005-->	550	ISO 46
-BUD	2006-->	550	ISO 46
-BVX	2005-->	550	ISO 46
-BKY	2005-->	550	ISO 46
-BVZ	2005-->	550	ISO 46
-BWA	2005-->	550	ISO 46
-BXE	2006-->	550	ISO 46

### SKODA ROOMSTER

-AXR	2006-->	550	ISO 46
-BLS	2006-->	550	ISO 46
-BME	2006-->	550	ISO 46
-BMS	2006-->	550	ISO 46
-BNM	2006-->	550	ISO 46
-BNW	2006-->	550	ISO 46
-BSW	2006-->	550	ISO 46
-BTS	2006-->	550	ISO 46
-BXW	2006-->	550	ISO 46

**SKODA SUPERB**

-AMX	2002-->	600	ISO 46
-AVB	2002-06	600	ISO 46
-AVF	2004-->	600	ISO 46
-AWT	2002-->	600	ISO 46
-AWX	2002-->	600	ISO 46
-AYM	2002-04	600	ISO 46
-AZM	2002-->	600	ISO 46
-BBG	2002-->	600	ISO 46
-BDG	2003-->	600	ISO 46
-BPZ	2007-->	600	ISO 46
-BSS	2005-->	600	ISO 46
-BSV	2005-->	600	ISO 46

**SMART****SMART FORFOUR W454**

-122950	2005-06	430	ISO 46
-134910	2004-06	430	ISO 46
-134911	2005-06	430	ISO 46
-134930	2004-06	430	ISO 46
-135950	2004-06	430	ISO 46
-639939	2004-06	430	ISO 46

**SMART FORTWO**

0.7	2003-->	450	
-----	---------	-----	--

**SMART FORTWO W450**

-160910	01/03->	450	ISO 46
-160920	2003-->	450	ISO 46
-660940	-->01/03	620	ISO 46
-660940	01/03->	450	ISO 46

**SMART ROADSTER W452**

-160921	2003-->	648	ISO 46
-160922	2003-->	648	ISO 46
-160923	2003-->	648	ISO 46

**SSANGYONG****SSANGYONG KORANDO**

	1997-99	700	ISO 100
--	---------	-----	---------

**SSANGYONG KYRON**

-D20DT	2005-->	650	
-D27DT	2006-->	650	
-G32D	2006-->	650	

**SSANGYONG MUSSO**

	1996-99	700	ISO 100
--	---------	-----	---------

**SSANGYONG REXTON**

-(2EV)	2002-06	1200	ISO 150
	2002-06	850	ISO 150

**SUBARU****SUBARU FORSTER**

	1998-02	600	ISO 100
	2002-->	600	ISO 100

<b>SUBARU IMPREZA 1</b>			
-EJ161	-->2000	650	ISO 100
-EJ16E	-->1996	650	ISO 100
-EJ16J	1997-97	650	ISO 100
-EJ18E	-->1996	650	ISO 100
-EJ18E	1997-98	600	ISO 100
-EJ201	1998-00	600	ISO 100
-EJ205	1998-00	600	ISO 100
-EJ20E	1995-96	650	ISO 100
-EJ20E	1997-98	600	ISO 100
-EJ20G	1994-96	650	ISO 100
-EJ20G	1997-98	600	ISO 100
<b>SUBARU IMPREZA 2</b>			
-EJ161	-->2001	500	ISO 150
-EJ161	2002-06	500	ISO 100
-EJ201	-->2001	500	ISO 150
-EJ201	2002-06	500	ISO 100
-EJ205	-->2001	500	ISO 150
-EJ205	2002-06	500	ISO 100
-EJ207	2002-06	500	ISO 100
-EJ251	2002-06	500	ISO 100
<b>SUBARU JASTY G3X</b>			
-M13A	2004-->	430	
-M15A	2004-->	430	
<b>SUBARU LEGACY</b>			
	1994-95	650	ISO 46
	1996	650	ISO 100
	1997-99	600	ISO 100
	2000-03	650	ISO 100
	2003-06	400	ISO 46
<b>SUBARU SVX</b>			
	1994-97	650	ISO 46
<b>SUZUKI</b>			
<b>SUZUKI ALTO</b>			
-RF410	2002-06	400	ISO 46
-SH410	1997-02	550	
	1997-2004	550	
<b>SUZUKI BALENO I</b>			
-G13BB	1995-00	600	
-G16B	1995-00	600	
-J18A	1996-00	600	
<b>SUZUKI BALENO II</b>			
-G13BB	2000-03	600	
-G16B	2000-03	600	
-J18A	2000-03	600	
<b>SUZUKI CAPPUCCINO</b>			
	-->1998	600	
<b>SUZUKI CARRY</b>			

-G13BB	1999-00	530	
-G13BB	2000-06	530	

### SUZUKI GRAN VITARA 1

-G16B	1998-02	550	ISO 46
-G16B	2002-05	400	ISO 46
-H25A	1998-01	550	ISO 46
-H25A-ND	2001-05	400	ISO 46
-H25A-Seik	01-05	450	ISO 46
-J20A	1998-02	500	ISO 46
-J20A	2002-05	400	ISO 46
-RF	1998-02	440	ISO 46
-RHW	2003-06	620	ISO 46
-RHW-(2EV)	03-02	800	ISO 46
-RHZ	2000-03	440	ISO 46
XL7-H27A	>05	620	ISO 46
XL7-H27A-2EV	>05	780	ISO 46
XL7-H27B	>05	620	ISO 46
XL7-H27B-2EV	>05	800	ISO 46
XL7-RHW	2003-05	620	ISO 46
XL7-RHW-2EV	>05	800	ISO 46

### SUZUKI GRAN VITARA 2

-F9Q	2007-->	570	
-H27A	2007-->	570	
-J20A	2005-->	570	
-M16A	2005-->	570	

### SUZUKI IGNIS (RG)

-M13A	2000-06	360	
-------	---------	-----	--

### SUZUKI IGNIS (RM)

-M13A-VVT	03-07	430	
-M15A-VVT	03-07	430	
-Z13DT	2003-07	480	ISO 46

### SUZUKI JIMNY

-G13BB	1999-06	550	
-K6A	1999-06	550	
-K9K	2003-06	650	
-M13A	2000-06	550	

### SUZUKI LIANA

-8HY	2005	650	
-M13A	2001-->	500	
-M16A	2001-06	500	
D	2001-->	460	

### SUZUKI SUPER CARRY

MOTOR-G-13		530	ISO 46
------------	--	-----	--------

### SUZUKI SWIFT

-M13A	2004-->	370	
-Z13DT	2004-->	370	ISO 46
M15A-VVT	2004-->	370	

### SUZUKI SX4

-D19AA	2006-->	430	ISO 46
939A1-4x4	2006->	430	ISO 46
939A1.000	2006->	430	ISO 46
D19AA(4x4)	2006->	430	ISO 46
M15A-VVT	2006-->	430	ISO 46
<b>SUZUKI WAGON R</b>			
-K10A	1997-00	550	
-K12A	1997-00	550	
	2000-06	500	
<b>SUZUKI WAGON R +</b>			
-G10	2004-->	475	
-G10A	2000-04	475	
-G13BB	2000-04	475	
-Z10XEP	2005-->	475	
-Z12XEP	2005-->	475	
-Z13DT	2003-->	480	ISO 46
M13A-VVT	2005-->	475	
<b>SUZUKI XL7</b>			
-(2EV)	2003-->	800	
	2003-->	550	
<b>TATA</b>			
<b>TATA SAFARI</b>			
	1999-04	1150	ISO 46
<b>TOYOTA</b>			
<b>TOYOTA 4 RUNNER</b>			
2,7i-16v	2000->	750	ISO 46
3,0i	89-95	800	ISO 46
3,4i	2000-->	450	ISO 46
3-D	1994-->	750	ISO 46
<b>TOYOTA AURIS</b>			
	2007-->	440	ISO 46
<b>TOYOTA AVENSIS</b>			
	1997-03	450	ISO 46
	2003-->	440	ISO 46
<b>TOYOTA AVENSIS VERSO</b>			
-(2EV)	2001-06	800	ISO 46
	2001-06	500	ISO 46
<b>TOYOTA AYGO</b>			
-DIESEL	2005-06	500	ISO 46
	2005-06	450	ISO 46
<b>TOYOTA CAMRY</b>			
	2001-06	550	ISO 46
<b>TOYOTA CARINA</b>			
	-->1998	750	ISO 46
<b>TOYOTA CELICA</b>			
	-->1999	650	ISO 46
	1999-02	650	ISO 100
	2002-->	460	ISO 46

<b>TOYOTA COROLLA</b>			
-DIESEL	1997-99	650	ISO 100
-DIESEL	1999-->	550	ISO 46
	1994-97	750	ISO 100
	1999-01	650	ISO 100
	2001-->	490	ISO 46
	2002-06	520	ISO 46
<b>TOYOTA COROLLA VERSO</b>			
-DIESEL	2001-->	550	
	2001-->	530	
	2004-06	470	ISO 46
<b>TOYOTA DYNIA</b>			
-DIESEL	1995-01	700	
	1995-99	550	
<b>TOYOTA HI-ACE</b>			
-(2EV)	1996-->	1400	ISO 46
	-->1995	750	
	1996-->	850	ISO 46
	1996-05	550	
<b>TOYOTA HI-LUX</b>			
1KZT	-->1996	750	
	->96	800	
	1997-->	550	
	1997-05	600	ISO 46
	2002-->	480	ISO 46
<b>TOYOTA L.CRUIS(2EV+SC)</b>			
2T	2004-->	880	ISO 46
	2004-->	930	ISO 46
<b>TOYOTA L.CRUISER(2EV)</b>			
3,0TD	-->1996	1650	ISO 46
3.4	1996-02	1000	ISO 46
	2004-->	830	ISO 46
<b>TOYOTA L.CRUISER(SC)</b>			
1G	2004-->	730	ISO 46
1K	2004-->	780	
2T	2004-->	730	
2T	2004-->	780	
3R	2004-->	780	ISO 46
<b>TOYOTA LANDCRUISER</b>			
(22R)2400	85-86	700	ISO 46
(22R)2400-(2EV)		1400	ISO 46
1G	2004-->	630	ISO 46
1K	2004-->	680	ISO 46
2,4TD-(2EV)	95	1600	ISO 46
2.4-(2EV)	88-96	1600	ISO 46
2.7-(2EV)	96-99	950	ISO 46
2.7-16v	96-99	700	ISO 46
2T	2004-->	630	ISO 46

3,0TD	1996-02	700	ISO 46
3,0TD (2EV)1K	>96	1600	ISO 46
3,0TD(2EV)	96-02	950	ISO 46
3,0TD-1KZT	>96	900	ISO 46
3.4	1996-02	750	ISO 46
3.4-24v	96-->	700	ISO 46
3.4-24v-(2EV)	96	950	ISO 46
3RL	2004-->	680	ISO 46
4,2D	-->2001	700	ISO 46
4,2D-(2EV)	90-01	950	ISO 46
4,2TD	-->1994	1400	
4,2TD	-->1995	900	ISO 46
4,2TD	-->94	950	
4,2TD	1995-98	900	ISO 46
4,2TD	1998-02	1100	ISO 46
4,2TD (2EV)	90-95	1600	ISO 46
4,2TD-24V	95-98	900	ISO 46
4,2TD-24V	98-->	850	ISO 46
4,2TD-24V-(2EV)		1600	ISO 46
4.5	1995-98	900	ISO 46
4.7	1998-02	1100	ISO 46
5L	2004-->	680	ISO 46
D	-->1995	950	

### TOYOTA LITE-ACE

3-D-SW	98-->	550	
	-->1995	750	

### TOYOTA MR2

-W3	1999-06	500	ISO 46
2-16V	89-99	850	ISO 46
	1994-98	900	ISO 46
	1999-06	530	ISO 46

### TOYOTA PASEO

1,5i-16V	91-99	600	ISO 100
----------	-------	-----	---------

### TOYOTA PICNIC

2-16V	96-01	750	ISO 46
2.2-TD	97-01	750	ISO 46

### TOYOTA PREVIA

-(2EV)	-->2000	1200	ISO 46
-(2EV)	2000-01	910	ISO 46
2,0TD	2001-->	700	ISO 46
2,0TD-(2EV)	01->	900	ISO 46
2,2TD	92-01	750	ISO 46
2,4i-16v	2000->	800	ISO 46
2,4i-16v	90-99	800	ISO 46
	2000-02	730	ISO 46

### TOYOTA PRIUS

1,5i	00-03	450	ISO 100
1,5i-16V	03-->	470	ISO 100

	2004-->	470	ISO 100
<b>TOYOTA RAV4</b>			
1.8-16V	00-06	500	ISO 46
2,4i	03-06	500	ISO 46
2-16V	00-06	500	ISO 46
2-16V	94-00	800	ISO 46
2-TD	01-06	550	ISO 46
	1994-00	750	ISO 46
	2000-06	540	ISO 46
	2006-->	430	ISO 46
<b>TOYOTA STARLET</b>			
1	>96	600	ISO 46
1.3-12V	-->1996	600	
1.3-16V	-->1999	600	
	1994-96	600	ISO 46
	1996-99	650	ISO 46
<b>TOYOTA SUPRA</b>			
	-->1997	750	ISO 46
<b>TOYOTA YARIS</b>			
1-16V	99-02	500	ISO 46
1-VVT-i	05-->	370	
1.3-16V	05-->	370	
1.3-16V	99-05	500	ISO 46
1.3-VVT-i	06-->	370	
1.5-16V	01-05	500	ISO 46
1.5-VVT-i	06-->	370	
<b>TOYOTA YARIS Diesel</b>			
1.4-D-4D	05-->	370	
1.4-TD	01-05	500	ISO 46
<b>TOYOTA YARIS Verso</b>			
1.3-16V	00-05	450	ISO 46
1.4-TD	01-05	450	ISO 46
1.5-16V	00-05	450	ISO 46
<b>VOLKSWAGEN</b>			
<b>VOLKSWAGEN BEETLE</b>			
	1998-06	750	ISO 46
<b>VOLKSWAGEN BORA</b>			
-4Mot	1999-05	775	ISO 46
	1998-05	775	ISO 46
<b>VOLKSWAGEN CADDY</b>			
	1995-04	850	ISO 46
	2004-06	550	ISO 46
<b>VOLKSWAGEN CALIFORNIA 4MOT</b>			
-(2EVAP)	2004-->	1400	
	2004-->	1000	
<b>VOLKSWAGEN CALIFORNIA D</b>			
4MOT	2004-->	1000	
4MOT-2EVAP	2004	1400	

SYNC	2002-03	1000	
SYNC-(2EVAP)	-->03	1400	
<b>VOLKSWAGEN CALIFORNIA SYNC</b>			
-(2EVAP)	2002-03	1400	
	2002-03	1000	
<b>VOLKSWAGEN CARAVELLE</b>			
-(2EVAP)	1994-->	1400	
	1994-->	1000	
<b>VOLKSWAGEN CORRADO</b>			
	->1995	900	ISO 46
<b>VOLKSWAGEN CRAFTER D</b>			
	2006-->	740	
<b>VOLKSWAGEN EOS</b>			
	2006-->	525	
<b>VOLKSWAGEN FOX</b>			
	2005-->	450	
<b>VOLKSWAGEN GOLF 3</b>			
	-->1999	850	ISO 46
<b>VOLKSWAGEN GOLF 4</b>			
	1998-03	800	ISO 46
<b>VOLKSWAGEN GOLF 5</b>			
PLUS-T.T.	2005->	525	ISO 46
T.T.	2003-->	525	ISO 46
	2003-06	550	ISO 46
<b>VOLKSWAGEN GOLF JETTA</b>			
	2005-->	525	ISO 46
<b>VOLKSWAGEN LT T.T.</b>			
-Denso	1996-06	800	ISO 46
-Sanden	1996-06	800	ISO 46
<b>VOLKSWAGEN LUPO</b>			
-CALSONI	1999-05	600	ISO 46
-DENSO	2000-05	600	ISO 46
-SANDEN	1998-00	750	ISO 46
<b>VOLKSWAGEN MULTIVAN</b>			
-(2EVAP)	2003-->	1400	
	2003-->	1000	
<b>VOLKSWAGEN PASSAT</b>			
-DENSO	1996-01	700	ISO 46
-W8	2000-05	525	ISO 46
-ZEXEL	1996-01	725	ISO 46
	-->1997	1200	
	2000-05	625	ISO 46
<b>VOLKSWAGEN PASSAT 4</b>			
	-->2005	650	ISO 46
<b>VOLKSWAGEN PASSAT 5</b>			
	2005-->	600	ISO 46
<b>VOLKSWAGEN PHAETON</b>			
	2002-->	625	ISO 46

<b>VOLKSWAGEN POLO</b>			
-SD6V12	1999-01	550	ISO 46
-SD7B10	1994-99	750	ISO 46
<b>VOLKSWAGEN POLO 3</b>			
-SD7B10	-->1994	750	ISO 46
	-->1994	900	ISO 46
<b>VOLKSWAGEN POLO 4</b>			
-SD7B10	1994-01	750	ISO 46
	1994-01	900	ISO 46
<b>VOLKSWAGEN POLO 5</b>			
	2005-->	525	
<b>VOLKSWAGEN SHARAN</b>			
-(2EV)	1995-00	1400	ISO 46
-(2EV)	2000-06	1050	ISO 46
	1995-00	1000	ISO 46
	2000-06	750	ISO 46
<b>VOLKSWAGEN TOUAREG</b>			
-(2EV)	2002-->	1050	ISO 46
-(2EV)	2004-->	1000	ISO 46
C.7SEU16C	2002-->	700	ISO 46
C.7SEU17C	2004-->	700	ISO 46
<b>VOLKSWAGEN TOURAN</b>			
	2003-06	550	ISO 46
	2004-->	500	ISO 46
<b>VOLKSWAGEN TRANSPORTER</b>			
(2EV)	>0.6.00-03	1400	ISO 46
-(2EV)	-->1995	1400	ISO 46
-(2EV)	0.6>00-03	1400	ISO 46
-(2EV)	1995-02	1400	ISO 46
-SD7V16	2003-05	950	ISO 46
-mot-AMV	2000-02	1150	ISO 46
	-->1995	1000	ISO 46
	0.6>00-03	1000	ISO 46
	1995-02	1000	ISO 46
	2003-06	750	ISO 46
	>0.6.00-03	1000	ISO 46
<b>VOLKSWAGEN VENTO T.T.</b>			
-HARRIS	-->1997	850	ISO 46
-SANDEN	-->1997	850	ISO 46
<b>VOLVO</b>			
<b>VOLVO 440</b>			
-SANDEN	-->1997	650	ISO 46
-ZEXEL	-->1997	650	ISO 46
<b>VOLVO 460</b>			
-SANDEN	-->1997	650	ISO 46
-ZEXEL	-->1997	650	ISO 46
<b>VOLVO 480</b>			
-SANDEN	-->1996	650	ISO 46

<b>VOLVO 850</b>			
	-->2000	800	ISO 46
<b>VOLVO 900</b>			
-(Zexel)	-->1998	950	ISO 46
	-->1998	950	ISO 100
<b>VOLVO 940</b>			
-SANDEN	-->1997	900	ISO 100
-SANDEN	-->1997	950	ISO 100
-SEIKO	-->1997	900	ISO 100
-SEIKO	-->1997	950	ISO 100
-ZEXEL	-->1997	900	ISO 46
-ZEXEL	-->1997	950	ISO 46
<b>VOLVO 960</b>			
-SANDEN	-->1997	900	ISO 100
-SEIKO	-->1997	900	ISO 100
-ZEXEL	-->1997	900	ISO 46
<b>VOLVO C30</b>			
	2006-->	535	ISO 46
<b>VOLVO C70</b>			
	1998-06	825	ISO 46
	2006-->	535	ISO 46
<b>VOLVO S40</b>			
-Diesel	1996-04	900	ISO 46
-Diesel	2004-->	530	
1,8GD	1998	750	ISO 46
1,8GD	1999-02	850	ISO 46
D	1996-98	900	ISO 46
D	1999-02	850	ISO 46
	1995-04	800	ISO 46
	2004-->	530	
	2004-2006	535	ISO 46
<b>VOLVO S60</b>			
	2000-06	1000	ISO 46
<b>VOLVO S70</b>			
-Diesel	1997-00	800	ISO 46
	1997-00	825	ISO 46
<b>VOLVO S80</b>			
	1998-->	1000	ISO 46
	1998-06	1000	ISO 46
	2006-->	620	ISO 46
<b>VOLVO S90</b>			
	1997-99	900	ISO 100
<b>VOLVO V40</b>			
-Diesel	1996-04	900	ISO 46
	1995-04	900	ISO 46
	2004-06	530	ISO 46
<b>VOLVO V50</b>			
	2004-->	535	ISO 46

<b>VOLVO V70</b>			
	1997-00	825	ISO 46
	2000-05	1000	ISO 46
	2006-07	750	ISO 46
<b>VOLVO V90</b>			
	1997-99	900	ISO 100
<b>VOLVO XC70</b>			
	2000-02	1000	ISO 46
	2002-->	700	
<b>VOLVO XC770</b>			
	2005-06	700	ISO 46
<b>VOLVO XC90</b>			
-(2EV)	2002-06	1300	ISO 46
	2002-04	1000	ISO 46
<b>VOLVO TRUK</b>			
<b>VOLVO TRUK F10 / F12</b>			
	1991-->	1400	
<b>VOLVO TRUK F16</b>			
	-->1996	1450	
<b>VOLVO TRUK FH12 / FH16</b>			
	2001-05	1250	
<b>VOLVO TRUK FL6</b>			
	-->1999	1150	
<b>VOLVO TRUK FM10</b>			
	1999-->	1150	
<b>VOLVO TRUK FM12</b>			
	1998-->	1500	
<b>VOLVO TRUK FM7 / FM9</b>			
	1996-->	1150	