


FRONT BUMPER REMOVAL ALFA ROMEO GT



1/. Working from the top with the bonnet open.

Undo the 4 upper bumper bolts (1).

2/. Working from under the car.

Prise up retainer and disconnect the electrical connector from the front turn signals (2).

3/. From under the car again.

a/. Undo the bumper side bolts (3).

b/. Remove the bumper (4a) releasing it from the side retainers (4b) and releasing the centering pins (4c).