

Alfa Romeo Control

FUNCTIONS NOT CHECKED	CHECKED FUNCTIONS		
	Key in POS. 1 Engine switched off	Key in POS. 1 Engine switched off TEST button pressed	Engine running
Seat heating	Safety belts	Safety belts	Brake oil level
Position lamps	W. lamp, led, LCD display	W. lamp, led, LCD display	Engine oil min. press.
Low beam lights	Eng. oil min. press. w. l.	Eng. oil min. press. w. l.	Door opening
High beam lights	Engine coolant level	Engine coolant level	Eng. cool. max. temp.
Turning lights	W.screen washer fluid l.	W.screen washer fluid l.	Fuel reserve
Fog lamps	Brake oil level	Brake oil level	Stop lamps*
Rear fog lamps	Engine oil level	Engine oil level	Electr. Suspensions*
Heated rear window	Brake pad wear	Brake pad wear	A. Gearbox (W.F.)*
Anti-theft	A. Gearbox w.lamp	A. Transm. (W.F., W.T.)	A. Gearbox (W.T.)
Electr. Inj and Ignit. Sys.	Electr. Suspensions	Electr. Suspensions	
Air bag	Eng. cool. max. temp. w.l.	Eng. cool. max. temp. w.l.	
Anti-lock Sys (ABS)	Stop lamps	Stop lamps	
	Handbrake actuated	Handbrake actuated	
	Fuel reserve	Fuel reserve	
	Door opening	Door opening	

(*): Faulty conditions stored in memory with the engine running and displayed during the "Test phase".

Note. The Electr. Inj and Ignit. Sys, Air bag e Anti-lock Sys (ABS) are fitted with an internal check circuit connected to the instrument panel warning lamps.